

OPERATOR'S MANUAL

VACMASTER® 15T TIER III DIESEL ABRASIVE VACUUMS



**BUILT MARCO
TOUGH**
MARCO MANUFACTURED

⚠ WARNING

Before using this equipment, read, understand and follow all instructions in the Operator's Manuals provided with this equipment. If the user and/or assistants cannot read or understand the warnings and instructions, the employer of the user and/or assistants must provide adequate and necessary training to ensure proper operation and compliance with all safety procedures pertaining to this equipment. If Operator's Manuals have been lost, please visit www.marco.us, or contact Marco at 563.324.2519 for replacements. Failure to comply with the above warning could result in death or serious injury.

Marco®

Company Profile

Since 1944, Marco has developed a strong tradition of providing innovative and reliable products and services to the surface preparation and protective coatings industries. We are the world's premier provider of Abrasives, Blasting, Coating, Dust Collectors, Engineered Systems, Rental, Safety, Service, Repair, & Modernization, and Vacuums.

Through innovative designs and a total commitment to quality, Marco manufactures products that increase production rates, create a safer workplace, and reduce maintenance costs. Marco's industry experience, manufacturing capabilities, legendary customer service, product availability, logistics services, and technology leadership is your assurance that we deliver high quality products and services, providing the best value to you, our customer.

The Marco Difference

- **Industry Experience** – With Marco on your team, you have access to expertise which can only come from decades of industry leadership. We have organized our engineering department, production specialists, customer operations, and safety support into a "Center of Competence." As a Marco customer, you have access to hundreds of years of cumulative experience related to your operations.
- **Manufacturing Excellence** – Marco is a U.S. based, ISO 9001:2008 certified manufacturer of equipment for the Surface Preparation and Protective Coatings industries. Marco's engineers benchmark the industry to ensure that we design and manufacture superior products that set the "Gold Standard" for performance, safety, and quality.
- **Legendary Customer Service** – Marco's legendary customer service team is staffed by friendly, highly-trained individuals who are focused on providing the highest level of product support, order accuracy, and customer satisfaction.
- **Product Availability** – We stock over 10,000 SKU's and have more than 45 shipping locations to serve North American and International markets for all major brands of blasting and coating equipment. As the largest provider of surface preparation and protective coatings equipment in the world, our inventory levels and product availability are unmatched.
- **Logistics Services** – Marco's in-house logistics team is dedicated to moving your shipment anywhere in the world. We move more than 14,000 truckloads every year, allowing you to save on freight costs by leveraging our buying power. Lower your process costs with a single invoice, which includes product and freight.
- **Technology Leadership** – Our website provides: Operator's Manuals, Part Numbers and Schematics Guides, SDS information, and Features & Specifications Guides, providing access to information 24/7. Our Extranet application allows you to receive quotes and place orders online. Our Intranet maintains a complete record of your purchase history to assist with ongoing support of your existing equipment and future purchasing decisions.

Vision Statement

Marco is the world's premier provider of Abrasives, Blasting, Coating, Dust Collectors, Engineered Systems, Rental, Safety, Service, Repair, & Modernization, and Vacuums.

Mission Statement

Marco provides strong leadership and innovation to the surface preparation and protective coatings industries. We dedicate our efforts to the continuous improvement of our products, services, processes, people, and most importantly, the quality of our customer's experience.

Quality Statement

Marco is committed to providing superior quality in the design, manufacturing, distribution, rental, service, and repair of our products. Our ISO 9001:2008 certification extends throughout all operations in all locations. Continuous improvement of our processes and supply chain Integration comprise the core of our business strategy for delivering exceptional quality and value in all Marco products and services.

Management Philosophy

We are a company dedicated to the success of every customer and associate. We discuss, debate, challenge, measure, and test our ideas. We will be boundless and limitless in our passion to improve. Through sound leadership and dedicated associates, we will ensure a long term, profitable future for Marco, our associates, customers, and suppliers.

DEFINITION OF TERMS

DANGER

This is an example of danger. This indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.

CAUTION

This is an example of a caution. This indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It can also be used to alert against unsafe practices.

WARNING

This is an example of a warning. This indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

NOTICE

This is an example of a notice. This indicates policy or practice directly related to safety of personnel or protection of property.

TABLE OF CONTENTS

| | | | |
|---|-----------|--|-----------|
| Company Profile | 1 | Remove & Install Auxiliary Pulser Manifold . . . | 39 |
| Definition of Terms | 2 | Remove & Install Vacuum Light Bar | 39 |
| Air & Abrasive Consumption Chart | 8 | Remove & Install Timer Board | 40 |
| Daily Pre-Operation Checklist | 10 | Remove & Install Air Dryer | 41 |
| Operating Instructions | 11 | Remove & Install Alcohol Evaporator | 41 |
| Description | 11 | Remove & Install Vacuum Control Box. | 42 |
| Operational Requirements | 11 | Remove & Install Blower | 43 |
| Towing Safety Instructions | 11 | Remove & Install Butterfly Springs | 46 |
| Operating Instructions | 11 | Remove & Install Filter Bags | 47 |
| Connect Vacuum Hose | 14 | Remove & Install Filter Cartridge | 48 |
| Raise and Lower Collection Hopper | 15 | Remove & Install Fuel Tank | 49 |
| Pre-Startup | 16 | Remove & Install Front Emergency-Stop Station | 50 |
| Unit Startup & Shutdown | 17 | Remove & Install Pendant Emergency-Stop Station | 51 |
| Adjust Vacuum Timer | 19 | Remove & Install Hopper Magnehelic Gauge . | 52 |
| Pulser System Startup | 20 | Remove & Install Blower Filter Magnehelic Gauge | 53 |
| Reading Magnehelic Gauge | 21 | Remove & Install Pneumatic Piston Vibrators . | 54 |
| Lubricate Grease Points | 22 | Disassemble & Assemble Diaphragm Valve . . | 54 |
| Specifications | 24 | Check Lubricator Oil Level | 55 |
| Maintenance | 25 | Remove & Install Lubricator | 56 |
| Adjust Tension of Blower Drive Belt | 25 | Remove & Install Hopper Wear Plates | 57 |
| Adjust Pulse Separation | 26 | Remove & Install Hopper Access Door Wear Plate | 59 |
| Hydraulic System Schematic | 27 | Remove & Install Double Lock Valve Assembly | 60 |
| Remove & Install Pressure Tank | 28 | Hazard Identification Decals | 61 |
| Remove & Install Blower Drive Belt Assembly | 29 | Troubleshooting | 65 |
| Remove & Install Engine Assembly | 31 | Assembly Part Numbers and Schematics | 67 |
| Remove & Install 12-Volt DC Hydraulic Power Unit With Tank | 32 | Front Assembly | 67 |
| Remove & Install Compressor | 33 | Rear Assembly | 69 |
| Remove & Install Governor | 36 | Right Side Front Assembly | 71 |
| Remove & Install Clutch | 37 | Right Side Center Assembly | 73 |
| Remove & Install Vacuum Timer Control Box. . | 37 | | |
| Remove & Install Pulser Manifold | 38 | | |

TABLE OF CONTENTS

| | |
|--|------------|
| Right Side Rear Assembly | 75 |
| Left Side Front Assembly | 77 |
| Left Side Center Assembly | 79 |
| Left Side Rear Assembly | 81 |
| Double Lock Valve Assembly | 83 |
| Fuel Tank | 84 |
| Fan Belt Assembly | 85 |
| Intake Filter Housing. | 86 |
| Vacuum Light Bar | 87 |
| Pneumatic Piston Vibrators | 88 |
| Pulser System Assembly | 89 |
| Filter Bag Pulsers | 91 |
| Emergency-Stop Stations. | 92 |
| Compressor Assembly | 93 |
| Compressor Governor | 95 |
| Vacuum Hose Support Bracket | 96 |
| Trailer | 97 |
| Wear Plates and Baffles | 99 |
| Hydraulic Hoses | 101 |
| Limited Warranty | 102 |
| Disclaimer of Warranty | 102 |
| Exclusive Remedy for Warranty Claims | 102 |
| Limitation of Remedies | 102 |

HAZARD IDENTIFICATIONS

WARNING

Failure to comply with ANY WARNING listed below could result in death or serious injury.

- ▶ OSHA sets exposure limits to protect workers from exposure to respirable crystalline silica, 29 CFR 1910.1053. Airborne dust could increase the exposure levels beyond permissible limits. Breathing dust containing silica could cause silicosis, a fatal lung disease. Breathing dust during abrasive blasting operations, post-blast cleaning operations, and/or servicing equipment within the abrasive blasting area may expose an individual to conditions that could cause asbestosis, lead poisoning and/or other serious or fatal diseases. Harmful dust containing toxic material from abrasives or surfaces being abrasive blasted can remain suspended in the air for long periods of time after abrasive blasting has ceased. A NIOSH-approved, well-maintained, respirator designed for the specific operation being performed must be used by anyone abrasive blasting, handling or using the abrasive, and anyone in the area of the dust.
- ▶ Contact NIOSH and OSHA offices to determine the proper respirator for your specific application. The air supplied to the respirator must be at least Grade D quality as described in Compressed Gas Association Commodity Specification G-7.1 and as specified by OSHA Regulation 1910.134. Ensure air filter and respirator system hoses are not connected to non-air sources or in-plant lines that may contain nitrogen, oxygen, acetylene or other non-breathable gases. Before removing respirator, use an air monitoring instrument to determine if the atmosphere is safe to breathe.
- ▶ You must comply with all OSHA, local, City, State, Province, Country and jurisdiction regulations, ordinances and standards, related to your particular work area and environment. Keep unprotected individuals out of the work area.
- ▶ Abrasive blasting operators must receive thorough training on the use of abrasive resistant attire which includes: supplied-air respirator, abrasive blasting suit, safety shoes, gloves, ear protection and eye protection. Protect the operator and bystanders by complying with NIOSH and OSHA Safety Standards.
- ▶ Inspect all equipment for wear or damage before and after each use. Failure to use Original Equipment Manufacturer repair parts and failure to immediately replace worn or damaged components could void warranties and cause malfunctions.
- ▶ OSHA requires abrasive blasting nozzles be equipped with an operating valve, which shall be designed to be held open only by continuous hand pressure and shall close immediately upon release of hand pressure (i.e., a “deadman” control). The valve shall not be modified in any manner that would allow it to remain open without the application of continuous hand pressure by the operator. Failure to comply with the above warning could result in release of high speed abrasive and compressed air resulting in death or serious injury. OSHA 29CFR 1910.244(b)
- ▶ Point the abrasive blasting nozzle only at the surface being abrasive blasted. Never point the abrasive blasting nozzle or abrasive stream at yourself or others.
- ▶ Unless otherwise specified, maximum working pressure of abrasive blasting pots and related components must not exceed 150 psi. Exceeding maximum working pressure of 150 psi could cause the abrasive blasting pot and components to burst. Failure to comply with the above warning could result in death or serious injury.
- ▶ Never weld, grind or drill on the abrasive blasting pot (or any pressure vessel). Doing so will void ASME certification and manufacturer’s warranty. Welding, grinding or drilling on the abrasive blasting pot (or any pressure vessel) could weaken the vessel causing it to burst. Failure to comply with the above warning could result in death or serious injury. (ASME Pressure Vessel Code, Section VIII, Division 1)
- ▶ This equipment is not intended for use in any area that might be considered a hazardous location, as described in the National Electric Code NFPA 70, Article 500. Use of this equipment in a hazardous location could cause an explosion or electrocution.
- ▶ Never attempt to move an abrasive blasting pot containing abrasive. Never attempt to manually move abrasive blasting pots greater than 6.5 cubic foot capacity. Always use at least two capable people to manually move an abrasive blasting pot on flat, smooth surfaces. A mechanical lifting device must be used if an abrasive blasting pot is moved in any other manner.

HAZARD IDENTIFICATIONS

WARNING

Failure to comply with ANY WARNING listed below could result in death or serious injury.

- ▶ This product is not for use in wet environments. Always use a Ground Fault Interrupter Circuit (GFIC) for all electrical power source connections. Use of this product in wet environments could create a shock or electrocution hazard.
- ▶ Frozen moisture could cause restrictions and obstructions in pneumatic control lines. Any restriction or obstruction in the pneumatic control lines could prevent the proper activation and deactivation of the remote control system, resulting in the release of high speed abrasive and compressed air. In conditions where moisture may freeze in the control lines an antifreeze injection system approved for this application can be installed.
- ▶ Do not cut, obstruct, restrict or pinch pneumatic control lines. Doing so could prevent the proper activation and deactivation of the remote control system, resulting in the release of high speed abrasive and compressed air.
- ▶ Use of Marco remote control switches with other manufacturer's remote control systems could cause unintended activation of remote control systems resulting in the release of high speed abrasive and compressed air. Only Marco remote control switches should be used with Marco remote control systems.
- ▶ Always be certain to have secure footing when abrasive blasting. There is a recoil hazard when abrasive blasting starts that may cause user to fall and misdirect the abrasive stream at operator or bystander.
- ▶ Never use an abrasive blasting pot or attachments as a climbing device. The person could slip and fall. The abrasive blasting pot could become unstable and tip over.
- ▶ For equipment manufactured by entities other than Marco, you must consult the Original Equipment Manufacturer operator's manuals, information, training, instructions and warnings, for the proper and intended use of all equipment.
- ▶ Flammable fumes, such as solvent and paint fumes in the work area can present an ignition or explosion hazard if allowed to collect in adequate concentrations. To reduce conditions that could result in a fire or an explosion, provide adequate ventilation, eliminate all ignition or spark sources, keep the work area free of debris, store solvents and solvent contaminated rags in approved containers, follow proper grounding procedures, do not plug/unplug power cord or turn on/off power switches when flammable fumes are present, keep a working fire extinguisher or provide another fire suppression system in the work area. Cease all operations and correct condition if a spark or ignition source is identified during operation.
- ▶ Always depressurize the entire system, disconnect all power sources and lockout/tagout all components before any maintenance or troubleshooting is attempted. Failure to comply with the above warning could cause electrical shock and inadvertent activation of equipment resulting in death or serious injury.
- ▶ Moving parts can present an area where crushing, pinching, entanglement or amputation may occur. Do not place body parts or foreign objects in any area where there are moving parts.
- ▶ Surfaces of heated supply tanks, drums and/or lines as well as the adjoining plumbing may become hot during normal use. Do not touch these heated surfaces without proper protection. Deactivate and allow sufficient time for all surfaces to cool before attempting any maintenance.
- ▶ High-pressure fluid from gun, hose leaks, or ruptured components can pierce skin and can cause a serious injury that may result in amputation. Do not point gun or spray tip at anyone or at any part of the body. Keep clear of any leaks or ruptures. Depressurize the entire system before attempting cleaning, inspecting, or servicing equipment.
- ▶ Exposure to toxic fluids or fumes may occur during the normal operation of this system. Before attempting to fill, use, or service this system, read SDS's to know the specific hazards of the fluids you are using. Always use proper Personal Protective Equipment when attempting to fill, use, or service this system.
- ▶ The use of this product for any purpose other than originally intended or altered from its original design is prohibited.
- ▶ Never hang objects from the abrasive blasting pot handle. Doing so may cause the abrasive blasting pot to become unstable and tip over.

HAZARD IDENTIFICATIONS

CAUTION

Failure to comply with ANY CAUTION listed below may result in minor or moderate injury.

- ▶ Static electricity can be generated by abrasive moving through the abrasive blasting hose causing a shock hazard. Prior to use, ground the abrasive blasting pot and abrasive blasting nozzle to dissipate static electricity.
- ▶ High decibel noise levels are generated during the abrasive blasting process which may cause loss of hearing. Ensure appropriate Personal Protective Equipment and hearing protection is in use.

NOTICE

Failure to comply with ANY NOTICE listed below could pose a hazard to personnel or property.


- ▶ See Air & Abrasive Consumption Chart for estimated abrasive consumption rates and required air flow (cubic feet per minute). Your system must meet these minimum requirements to ensure proper function and performance.
- ▶ Always use abrasive that is dry and properly screened. This will reduce the potential for obstructions to enter the remote control system, abrasive metering valve and abrasive blasting nozzle.
- ▶ Moisture build-up occurs when air is compressed. Any moisture within the abrasive blasting system will cause abrasive to clump, clogging metering valves, hoses and nozzles. Install an appropriately sized moisture separator at the inlet of the abrasive blasting system. Leave the moisture separator petcock slightly open to allow for constant release of water. If insufficient volume of air exists and petcock is unable to be left open (at all times) petcock should be opened frequently to release water.
- ▶ To reduce abrasive intrusion in the air supply hose, depressurize the abrasive blasting pot before shutting off air supply from compressor.
- ▶ Inspect abrasive blasting nozzle before placing into service. Damage to abrasive blasting nozzle liner or jacket may occur during shipping. If you receive a damaged abrasive blasting nozzle, contact your distributor immediately for replacement. Abrasive blasting nozzles placed into service may not be returned. Abrasive blasting nozzle liners are made of fragile materials and can be damaged by rough handling and striking against hard surfaces. Never use a damaged abrasive blasting nozzle.
- ▶ Abrasive blasting at optimal pressure for the abrasive used is critical to productivity. Example: For an abrasive with an optimal abrasive blasting pressure of 100 psi at the abrasive blasting nozzle, one pound per square inch of pressure loss will reduce abrasive blasting efficiency by 1.5%. A 10 psi reduction in air pressure will cause a 15% loss of efficiency. Use a Needle Pressure Gauge to identify pressure drops in your system. Consult with your abrasive supplier for the requirements of your abrasive.
- ▶ Replace abrasive blasting nozzle if liner or jacket is cracked or damaged. Replace abrasive blasting nozzle if original orifice size has worn 1/16" or more. Determine abrasive blasting nozzle wear by inserting a drill bit 1/16" larger than original size of abrasive blasting nozzle orifice. If the drill bit passes through abrasive blasting nozzle, replacement is needed.

AIR & ABRASIVE CONSUMPTION CHART

NOTICE

Failure to comply with ANY NOTICE listed below could pose a hazard to personnel or property.

- ▶ See Air & Abrasive Consumption Chart for estimated abrasive consumption rates and required air flow (cubic feet per minute). Your system must meet these minimum requirements to ensure proper function and performance.
- ▶ When it comes to air & abrasive mixtures, more is not necessarily better. Optimum abrasive blasting efficiency takes place when a lean air & abrasive mixture is used. To correctly set the abrasive metering valve, begin with the valve fully closed and slowly increase the amount of abrasive entering the airstream. As you increase the abrasive flow, watch for a “blue flame” at the exit of the abrasive blasting nozzle. Faster cutting, reduced abrasive consumption and lower clean up costs, are benefits of the “blue flame”.
- ▶ Abrasive blasting at optimal pressure for the abrasive used is critical to productivity. Example: For an abrasive with an optimal abrasive blasting pressure of 100 psi at the abrasive blasting nozzle, one pound per square inch of pressure loss will reduce abrasive blasting efficiency by 1.5%. A 10 psi reduction in air pressure will cause a 15% loss of efficiency. Use a Needle Pressure Gauge to identify pressure drops in your system. Consult with your abrasive supplier for the requirements of your abrasive.



“Blue Flame”

Air & Abrasive Consumption Chart*

| Nozzle Orifice | Pressure at the Nozzle (PSI) | | | | | | | | Air (in cfm), Abrasive & Compressor Requirements |
|-------------------------|------------------------------|---------------------|--------------------|----------------------|--------------------|----------------------|--------------------|---------------------|---|
| | 50 | 60 | 70 | 80 | 90 | 100 | 125 | 140 | |
| No. 2 (1/8") | 11 67 2.5 | 13 77 3 | 15 88 3.5 | 17 101 4 | 18 112 4.5 | 20 123 5 | 25 152 5.5 | 28 170 6.2 | Air (cfm) Abrasive (lbs/hr) Compressor Horsepower |
| No. 3 (3/16") | 26 150 6 | 30 171 7 | 33 196 8 | 38 216 9 | 41 238 10 | 45 264 10 | 55 319 12 | 62 357 13 | Air (cfm) Abrasive (lbs/hr) Compressor Horsepower |
| No. 4 (1/4") | 47 268 11 | 54 312 12 | 61 354 14 | 68 408 16 | 74 448 17 | 81 494 18 | 98 608 22 | 110 681 25 | Air (cfm) Abrasive (lbs/hr) Compressor Horsepower |
| No. 5 (5/16") | 77 468 18 | 89 534 20 | 101 604 23 | 113 672 26 | 126 740 28 | 137 812 31 | 168 982 37 | 188 1100 41 | Air (cfm) Abrasive (lbs/hr) Compressor Horsepower |
| No. 6 (3/8") | 108 668 24 | 126 764 28 | 143 864 32 | 161 960 36 | 173 1052 39 | 196 1152 44 | 237 1393 52 | 265 1560 58 | Air (cfm) Abrasive (lbs/hr) Compressor Horsepower |
| No. 7 (7/16") | 147 896 33 | 170 1032 38 | 194 1176 44 | 217 1312 49 | 240 1448 54 | 254 1584 57 | 314 1931 69 | 352 2163 77 | Air (cfm) Abrasive (lbs/hr) Compressor Horsepower |
| No. 8 (1/2") | 195 1160 44 | 224 1336 50 | 252 1512 56 | 280 1680 63 | 309 1856 69 | 338 2024 75 | 409 2459 90 | 458 2754 101 | Air (cfm) Abrasive (lbs/hr) Compressor Horsepower |
| No. 10 (5/8") | 308 1875 68.5 | 356 2140 79.5 | 404 2422 90 | 452 2690 100.5 | 504 2973 112 | 548 3250 122 | 663 3932 146 | 742 4405 165 | Air (cfm) Abrasive (lbs/hr) Compressor Horsepower |
| No. 12 (3/4") | 432 2672 96 | 504 3056 112 | 572 3456 127 | 644 3840 143 | 692 4208 154 | 784 4608 174.5 | 948 5570 209 | 1062 6238 236 | Air (cfm) Abrasive (lbs/hr) Compressor Horsepower |

*Abrasive consumption is based on abrasive with a bulk density of 100 lbs per Cubic Foot


NOTICE

Inspect abrasive blasting nozzle before placing into service. Damage to abrasive blasting nozzle liner or jacket may occur during shipping. If you receive a damaged abrasive blasting nozzle, contact your distributor immediately for replacement. Abrasive blasting nozzles placed into service may not be returned. Abrasive blasting nozzle liners are made of fragile materials and can be damaged by rough handling and striking against hard surfaces. Never use a damaged abrasive blasting nozzle.

NOTICE

Replace abrasive blasting nozzle if liner or jacket is cracked or damaged. Replace abrasive blasting nozzle if original orifice size has worn 1/16" or more. Determine abrasive blasting nozzle wear by inserting a drill bit 1/16" larger than original size of abrasive blasting nozzle orifice. If the drill bit passes through abrasive blasting nozzle, replacement is needed.

“THE BIG PICTURE”



DAILY PRE-OPERATION CHECKLIST

Daily Pre-operation Checklist

- ☐ 1. Abrasive
- ☐ 2. Air Compressor
- ☐ 3. Air Hose Couplings & Gaskets
- ☐ 4. Air Hose
- ☐ 5. Safety Cable
- ☐ 6. Ambient Air Pump*
- ☐ 7. Breathing Air Filter
- ☐ 8. CO Monitor
- ☐ 9. Breathing Line
- ☐ 10. Climate Control Device
- ☐ 11. Abrasive Blasting Suit
- ☐ 12. Gloves
- ☐ 13. Abrasive Blasting Nozzle
- ☐ 14. Lighting System*
- ☐ 15. Abrasive Blasting Nozzle Holder
- ☐ 16. Remote Control Switch
- ☐ 17. Supplied-Air Respirator
- ☐ 18. Control Line
- ☐ 19. Abrasive Blasting Hose
- ☐ 20. Abrasive Blasting Hose Couplings & Gaskets
- ☐ 21. Abrasive Metering Valve
- ☐ 22. Remote Control System
- ☐ 23. Moisture Separator
- ☐ 24. Abrasive Blasting Pot Exhaust Muffler
- ☐ 25. Abrasive Blasting Pot
- ☐ 26. Abrasive Blasting Pot Screen
- ☐ 27. Abrasive Blasting Pot Lid
- ☐ 28. Aftercooler*

* Optional or alternative device.
Ask your Marco Representative
for more details.

Abrasive – Select the correct Abrasive (1) for the application. Review the SDS (*Safety Data Sheet*) to ensure the correct PPE (*Personal Protective Equipment*) and Environmental Controls have been selected and are in place.

Air Compressor – Select an Air Compressor (2) of adequate size to support all equipment requirements. Refer to “Air & Abrasive Consumption Chart” for Abrasive Blasting Nozzle (13) air consumption requirements. Before connecting Air Hose (4), sample the air being produced by the air compressor (2) to ensure it is free of petroleum contaminants.

Air Hose, and Air Hose Couplings & Gaskets – Select Air Hoses (4) of sufficient size to support all subsequent volumetric requirements and with a sufficient PSI (*pound per square inch*) rating. Inspect all Air Hoses (4), and Air Hose Couplings & Gaskets (3) for damage or wear. Repair or replace damaged or worn components.

Abrasive Blasting Hose, Abrasive Blasting Hose Couplings & Gaskets, and Abrasive Blasting Nozzle Holder – Select an Abrasive Blasting Hose (19) that has an inner diameter 3 to 4 times larger than your Abrasive Blasting Nozzle (13). Inspect Abrasive Blasting Hose (19), Abrasive Blasting Hose Couplings & Gaskets (20), and Abrasive Blasting Nozzle Holder (15) for damage or wear. Repair or replace damaged or worn components.

Safety Cables – Install a Safety Cable (5) at each Abrasive Blasting Hose (19), and Air Hose (4) connection points.

Aftercooler and Moisture Separator – Ensure Aftercooler (28) is positioned on stable ground. Keep petcock drain of Moisture Separator (23) slightly open during use. Drain both devices after each use.

Supplied-Air Respirator, Breathing Line, Breathing Air Filter, Climate Control Device, CO Monitor, Ambient Air Pump – You MUST consult the Operator's Manual supplied with your Respiratory Equipment (6, 7, 8, 9, 10, 17) for ALL applicable instructions and warnings. Inspect all Respiratory Equipment components for damage or wear. Repair or replace damaged or worn components.

Abrasive Blasting Suit and Gloves – Select an abrasive-resistant Abrasive Blasting Suit (11) that is slightly oversized to allow ease of movement and allows air to flow around your body. Select abrasive-resistant Gloves (12) with a tight fit and a long cuff that overlaps the sleeve of the Abrasive Blasting Suit (11).

Abrasive Metering Valve and Abrasive Blasting Pot – Confirm Abrasive Blasting Pot (25) is positioned on stable ground. Inspect Abrasive Blasting Pot (25) and Abrasive Metering Valve (21) for damage or wear. Repair or replace damaged or worn components.

Abrasive Blasting Pot Screen and Abrasive Blasting Pot Lid – Always use an Abrasive Blasting Pot Screen (26) when filling Abrasive Blasting Pot (25) with Abrasive (1) to prevent debris from entering the Abrasive Blasting Pot (25). Remove Abrasive Blasting Pot Lid (27) before operating the Abrasive Blasting Pot (25). Install Abrasive Blasting Pot Lid (27) after use to protect the Abrasive Blasting Pot's (25) interior.

Remote Control System, Remote Control Switch, Control Line, – Inspect Remote Control System (22) and Control Line (18) for damage or wear. Repair or replace damaged or worn components. Ensure Control Line (18) fittings connected to the Remote Control System (22) are tight and free of leaks. Ensure Remote Control Switch (16) is functioning properly. Consult Remote Control Switch Operator's Manual for applicable instructions.

Abrasive Blasting Pot Exhaust Muffler – Inspect Abrasive Blasting Pot Exhaust Muffler (24) at start and end of daily use. Replace element of Abrasive Blasting Pot Exhaust Muffler (24) per Operator's Manual instructions.

Lighting System – Ensure the Lighting System (14) is connected to a proper power supply before use.

OPERATING INSTRUCTIONS

DANGER

D-506

Do not move vacuum while hopper is in raised position. Failure to comply with the above danger will result in death or serious injury.

WARNING

W-575

Ensure the surface is level, stable, and is sufficient to support the weight of the Device or System. Uneven or unstable surfaces, and/or surfaces that cannot support the gross weight of the Device or System could cause the Device or System to overturn. Failure to comply with the above warning could result in death or serious injury.

WARNING

W-601

Ground machine to a suitable ground before operation. Static discharge could result in a fire or an explosion. Failure to comply with above warning could result in death or serious injury.

WARNING

W-503

You must comply with all OSHA, local, City, State, Province, Country and jurisdiction regulations, ordinances and standards, related to your particular work area and environment. Keep unprotected individuals out of the work area. Failure to comply with the above warning could result in death or serious injury.

Description

The Vacmaster® 15T Tier III Diesel Abrasive Vacuums are a trailer mounted vacuum designed to convey granulated materials from a work area to a container for recycling or disposal. Using a powerful 174 HP Perkins diesel engine to drive the rotary lobe blower, the Vacmaster® 15T Tier III Diesel Abrasive Vacuums easily create 27" Hg of suction to quickly move large quantities of material from inside tanks, ship hulls, and containment areas, reducing clean up time on work sites. The large hopper with automatic direct dump gate can be raised and lowered to match the height of your disposal container. The Vacmaster® 15T Tier III Diesel Abrasive Vacuums can easily clean up surface preparation work sites of spent abrasives like garnet, coal slag, cooper slag, crushed glass, steel shot, steel grit, and aluminum oxide. Typical applications include blast yards, bridges, oil refineries, pipelines, shipyards, storage tanks, and water treatment plants.

Operational Requirements

This equipment is self-contained and powered by a Diesel engine. It will provide excellent service if properly maintained. There are no unique or complicated parts that require sophisticated maintenance procedures under normal operation. The diesel engine is equipped with automatic shutdowns for low oil pressure and high temperature.

The following may cause safety hazards or reduced performance:

- Improper installation and/or maintenance of components.
- Failing to properly secure unit from movement when not in transport.
- Exceeding 55 mph speed limit when towing unit.
- Operating the Vacmaster® 15T Tier III Diesel Abrasive Vacuums under electrical wires or near power cables of any kind.
- Raising the hopper without all four jack stands lowered and pinned.
- Standing under the raised Hopper without support struts pinned in place.

Towing Safety Instructions

- Due to the height of 11'2", extra caution is required for overhead clearance.
- Do not ship or transport via semi-truck trailer. The Vacmaster® 15T Tier III Diesel Abrasive Vacuums must be towed behind an appropriate motor vehicle.
- Be sure all lights on the trailer are functioning properly before traveling with this unit.
- Always tow the Vacmaster® 15T Tier III Diesel Abrasive Vacuums with the safety chains and the emergency brake cable attached to the towing vehicle.
- Before towing the Vacmaster® 15T Tier III Diesel Abrasive Vacuums, inspect the tires and the hitch mechanism for damage.
- Always tow the Vacmaster® 15T Tier III Diesel Abrasive Vacuums with the Hopper in the lowered and locked position.
- Always tow the Vacmaster® 15T Tier III Diesel Abrasive Vacuums with the Hopper completely empty and the discharge door secured in closed position.
- Tow vehicle must have electric brake controller.
- Do not exceed 55 mph speed limit.

Operating Instructions

Before use:

- Ensure the surface is level, stable, and is sufficient to support the weight of the unit. Block wheels to prevent unintended movement.
- Level Vacmaster® 15T Tier III Diesel Abrasive Vacuums by adjusting height using four Jack Stands (1) so that it is sitting no more than 5 degrees off level in any direction.

OPERATING INSTRUCTIONS

⚠ WARNING

W-520

The use of this product for any purpose other than originally intended or altered from its original design is prohibited. Failure to comply with the above warning could result in death or serious injury.

⚠ WARNING

W-505

Inspect all equipment for wear or damage before and after each use. Failure to use Original Equipment Manufacturer repair parts and failure to immediately replace worn or damaged components could void warranties and cause malfunctions. Failure to comply with the above warning could result in death or serious injury.

⚠ WARNING

W-596

Do not place any part of body into or over any suction inlet of vacuum or connected hose. Failure to comply with the above warning could result in death or serious injury.

⚠ WARNING

W-600

Do not use vacuum with hopper in raised position with winds greater than 28 MPH. Unit can tip over. Failure to comply with above warning could result in death or serious injury.

⚠ WARNING

W-599


Do not raise hopper unless area around and above unit is inspected and found to be free of electrical wires or other obstructions. Failure to comply with above warning could result in death or serious injury.

Before use (Cont.):

- Ground machine to a suitable ground.
- Perform daily lubrication. See Lubricate Grease Points.
- Connect vacuum hose. See Connect Vacuum Hose.
- Run vacuum hose and E-Stop Pendant (3) to suction site.
- Close Ball Valves (2).
- Raise collection hopper to working height. See Raise and Lower Collection Hopper.

During use:

- Monitor all fluid levels.
- Monitor air pressure.
- Monitor vacuum pressure
- Monitor both Magnehelic gauges.
- Monitor amount of material collected in catch container to prevent overflowing.



OPERATING INSTRUCTIONS

⚠ WARNING

W-505

Inspect all equipment for wear or damage before and after each use. Failure to use Original Equipment Manufacturer repair parts and failure to immediately replace worn or damaged components could void warranties and cause malfunctions. Failure to comply with the above warning could result in death or serious injury.

⚠ WARNING

W-596

Do not place any part of body into or over any suction inlet of vacuum or connected hose. Failure to comply with the above warning could result in death or serious injury.

⚠ WARNING

W-511

For equipment manufactured by entities other than Marco, you must consult the Original Equipment Manufacturer operator's manuals, information, training, instructions and warnings, for the proper and intended use of all equipment. Failure to comply with the above warning could result in death or serious injury.

NOTICE

N-536

When a dust collector is used to service a storage tank, ensure there is adequate ventilation to prevent tank collapse due to pressure imbalance between external and internal tank surfaces. Failure to properly ventilate storage tank may result in damage to property. If proper ventilation is in question, consult with tank manufacturer or engineer.

After use:



- See Unit Shutdown Instructions.
- Lower collection hopper. See Raise and Lower Collection Hopper.

Note: Allow diesel engine to idle for at least 5 minutes after it has been under load before shutting off.

- Shut unit down.
- Open Pulser System Ball Valve (1).
- Disconnect vacuum hose (*not shown*) from Inlet Port (2).



2



1

OPERATING INSTRUCTIONS

Connect Vacuum Hose

⚠ WARNING

W-562

Always depressurize the entire system, disconnect all power sources and lockout/tagout all components before any maintenance or troubleshooting is attempted. Failure to comply with the above warning could cause electrical shock and inadvertent activation of equipment resulting in death or serious injury.


⚠ WARNING

W-596

Do not place any part of body into or over any suction inlet of vacuum or connected hose. Failure to comply with the above warning could result in death or serious injury.

Note: Do not attach hose to vacuum inlet port while machine is running.

- 1) Ensure unit is off.
- 2) Attach Vacuum Hose (*not shown*) to Inlet Port (1).
- 3) Secure with Quick Disconnect Coupling (2).



OPERATING INSTRUCTIONS

Raise and Lower Collection Hopper

⚠ DANGER

D-504

Do not raise hopper unless vacuum is on a level surface and jack stands are down and secured using a proper device. Failure to comply with the above danger will result in death or serious injury.

⚠ DANGER

D-505

Do not leave hopper in raised position without support strut in place and secured using a proper device. Failure to comply with the above danger will result in death or serious injury.

⚠ WARNING

W-599

Do not raise hopper unless area around and above unit is inspected and found to be free of electrical wires or other obstructions. Failure to comply with above warning could result in death or serious injury.




⚠ WARNING

W-597

Always install safety struts when collection hopper is in raised position. Do not stand under collection hopper or between collection hopper and trailer when hydraulic cylinders are in raised position without support struts secured in place. Failure to comply with the above warning could result in death or serious injury.

Note: Do not leave the collection cylinder in the raised position without the support struts pinned in place.

- 1) Power up the unit. See Unit Startup and Shutdown.
- 2) Push "RAISE" Button (1), to raise collection hopper to about five feet above base.
- 3) Remove Pin (2) and pivot Support Strut (3) to Pin Hole (4) and insert pin. Repeat for opposite side.
- 4) Continue raising hopper to sufficient height to clear the collection device. When the proper height is reached, place Support Strut Pin (5) in the closest hole on the Support Struts (3). Repeat for opposite side.
- 5) Push "LOWER" Button (6), to gradually lower the hopper until it is resting on Support Strut Pins (5).
- 6) Reverse procedure to lower collection hopper.



OPERATING INSTRUCTIONS

Pre-Startup

WARNING

W-587

Escaping fluid under pressure can penetrate skin and tissue causing injury. Stop pump and relieve pressure before attempting maintenance or repair. Ensure all fittings are properly tightened before restoring pressure. If injury should occur, immediately seek medical attention. Failure to comply with the above warning could result in death or serious injury.



WARNING

W-586

Exposure to toxic fluids or fumes may occur during the normal operation of this system. Before attempting to fill, use, or service this system, read SDS's to know the specific hazards of the fluids you are using. Always use proper Personal Protective Equipment when attempting to fill, use, or service this system. Failure to comply with the above warning could result in death or serious injury.

Pre-Startup Instructions:

- 1) Check engine oil and coolant levels. See Engine Operator's Manual for instructions.
- 2) Check diesel fuel level using Fuel Gauge (1). Add diesel fuel, as needed.
- 3) Check hydraulic oil level using Dip Stick (2) on Hydraulic Oil Tank (3). Add hydraulic oil, as needed.



OPERATING INSTRUCTIONS

Unit Startup & Shutdown

⚠ DANGER

D-503

Do not vacuum flammable or combustible material. An explosion is possible. Failure to comply with the above warning will result in death or serious injury.

⚠ WARNING

W-506

Do not place any part of body into or over any suction inlet of vacuum or connected hose. Failure to comply with the above warning could result in death or serious injury.

⚠ CAUTION

C-514

High decibel noise levels are generated during the vacuum process which may cause loss of hearing. Ensure appropriate hearing protection is in use. Failure to comply with the above caution may result in minor or moderate injury.


Unit Startup Instructions:

- 1) Ensure Clutch Handle (2) is disengaged.
- 2) Turn Key (1) to "R" until Murphy PowerView fully comes online.
- 3) Turn key until engine starts, 30 seconds maximum. Release key when engine starts.
- 4) Run engine for approximately 5 minutes.

Note: Ensure that personnel are away from inlet duct opening.

Note: Rapid engagement of clutch may cause damage to clutch and belts to slip from pulleys.

- 5) Slowly engage clutch until fully engaged and handle is in its locked position.
- 6) On Vacuum Control Box (4), turn Vacuum Selector Switch (5) "ON".
- 7) Check Air Pressure Gauge (3) for 90-95 psi of air.
- 8) Start pulser system. See Pulser System Startup.
- 9) Adjust vacuum timer. See Adjust Vacuum Timer.
- 10) Turn Vibrator Selector Switch (7) "ON".
- 11) Ensure Pulse Selector Switch (6) is "ON".



OPERATING INSTRUCTIONS

Unit Startup & Shutdown Cont.

WARNING

W-503

You must comply with all OSHA, local, City, State, Province, Country and jurisdiction regulations, ordinances and standards, related to your particular work area and environment. Keep unprotected individuals out of the work area. Failure to comply with the above warning could result in death or serious injury.

WARNING




W-501

Breathing dust containing silica could cause silicosis, a fatal lung disease. Breathing dust during abrasive blasting operations, post-blast cleaning operations, and/or servicing equipment within the abrasive blasting area may expose an individual to conditions that could cause asbestosis, lead poisoning and/or other serious or fatal diseases. Harmful dust containing toxic material from abrasives or surfaces being abrasive blasted can remain suspended in the air for long periods of time after abrasive blasting has ceased. A NIOSH-approved, well-maintained, respirator designed for the specific operation being performed must be used by anyone abrasive blasting, handling or using the abrasive, and anyone in the area of the dust. Failure to comply with the above warning could result in death or serious injury.

Unit Shutdown Instructions:

Note: In the event of an emergency, press one of the Emergency-Stop Stations to cease operation of the system.

- 1) Allow all material to clear suction hose.
- 2) Decrease engine speed to Idle by turning Vacuum Selector Switch (1) "OFF".
- 3) Disengage Clutch Handle (4).
- 4) Turn Vibrator Selector Switch (3) "OFF".
- 5) Turn Pulse Selector Switch (2) "OFF".
- 6) Follow After Use instructions.



4

OPERATING INSTRUCTIONS

Adjust Vacuum Timer

WARNING

W-562

Always depressurize the entire system, disconnect all power sources and lockout/tagout all components before any maintenance or troubleshooting is attempted. Failure to comply with the above warning could cause electrical shock and inadvertent activation of equipment resulting in death or serious injury.

WARNING

This equipment is not intended for use in any area that might be considered a hazardous location, as described in the National Electric Code NFPA 70, Article 500. Use of this equipment in a hazardous location could cause an explosion or electrocution. Failure to comply with the above warning could result in death or serious injury.

WARNING


W-602

Stay clear of dump door while machine is in operation. Dump door activates automatically. Failure to comply with above warning could result in death or serious injury.

Note: Run times will need to be adjusted according to the bulk density of material being collected and length of hose.

Note: Dump Door (4) opens and closes automatically with timer control settings.

- 1) Inside Vacuum Timer Control Box (1), the "T2" Knob (3) controls the time that vacuum runs and the "T1" Knob (2) controls the time that vacuum is off (dump time).
- 2) Turn knobs clockwise to increase time and counterclockwise to reduce time.



OPERATING INSTRUCTIONS

Pulser System Startup

WARNING

W-562

Always depressurize the entire system, disconnect all power sources and lockout/tagout all components before any maintenance or troubleshooting is attempted. Failure to comply with the above warning could cause electrical shock and inadvertent activation of equipment resulting in death or serious injury.

WARNING

This equipment is not intended for use in any area that might be considered a hazardous location, as described in the National Electric Code NFPA 70, Article 500. Use of this equipment in a hazardous location could cause an explosion or electrocution. Failure to comply with the above warning could result in death or serious injury.

WARNING


W-590

When performing service or maintenance on systems or devices requiring access from an elevated position, you must comply with all OSHA, local, City, State, Province, Country and jurisdiction regulations, ordinances and standards, as related to working in elevated work areas. Failure to comply with the above warning could result in death or serious injury.

Pulser System Startup Instructions:

The Pulser System is a cleaning system for the filter bags. This system blows a burst of air into a set of filters to dislodge dust from the filters into the hopper. To change time duration of pulse, see Adjust Pulse Separation.

- 1) Ensure Ball Valves (2) are closed.
- 2) To Pulse, turn "PULSE" Switch (1) on control box to "On".
- 3) While powered, the pulser system should be easily heard. The timer controller will be factory set.
- 4) Material will fall from the filters to the bottom of the hopper to dump during the dump cycle.



OPERATING INSTRUCTIONS

Reading Magnehelic Gauge

WARNING

W-577

Before using this equipment, read, understand and follow all instructions in the Operator's Manuals with this equipment. If the user and/or assistants cannot read or understand the warnings and instructions, the employer of the user and/or assistants must provide adequate and necessary training to ensure proper operation and compliance with all safety procedures pertaining to this equipment. If Operator's Manuals have been lost, visit www.marco.us or call (563) 324-2519 for replacements. Failure to comply with the above warning could result in death or serious injury.


The Magnehelic Gauge provides a means to tell how clean the filter cartridges/bags are. It measures the static pressure and the resistance of air flow across the filters.

Magnehelic Gauge located on hopper

- New Filters will register approximately 1" water column (w.c.) on the gauge. Normal operating range for conditioned filters will show 20" – 30" (w.c.) on gauge.
- If Magnehelic Gauge is reading above the normal operating range, see Troubleshooting Section.

Magnehelic Gauge located near intake filter housing

- New Filters will register approximately 2" water column (w.c.) on the gauge. Normal operating range will register approximately 10" water column (w.c.) on the gauge.
- If Magnehelic Gauge reading climbs rapidly, stop operating the unit, perform shut-down procedure, and check pulser system and filter bags.
- If reading above 30" (w.c.), stop operating the unit immediately, perform shut-down procedure, check pulser system, and replace filter bags.



OPERATING INSTRUCTIONS

Lubricate Grease Points

WARNING

W-562

Always depressurize the entire system, disconnect all power sources and lockout/tagout all components before any maintenance or troubleshooting is attempted. Failure to comply with the above warning could cause electrical shock and inadvertent activation of equipment resulting in death or serious injury.

Lubricate Vacmaster® 15T Tier III Diesel Abrasive Vacuums at points indicated. Points are indicated by Lubrication Point Grease Daily Decal (1).




1

WARNING

W-587

Escaping fluid under pressure can penetrate skin and tissue causing injury. Stop pump and relieve pressure before attempting maintenance or repair. Ensure all fittings are properly tightened before restoring pressure. If injury should occur, immediately seek medical attention. Failure to comply with the above warning could result in death or serious injury.



OPERATING INSTRUCTIONS

Lubricate Grease Points (Cont)

WARNING

W-562

Always depressurize the entire system, disconnect all power sources and lockout/tagout all components before any maintenance or troubleshooting is attempted. Failure to comply with the above warning could cause electrical shock and inadvertent activation of equipment resulting in death or serious injury.

WARNING


W-587

Escaping fluid under pressure can penetrate skin and tissue causing injury. Stop pump and relieve pressure before attempting maintenance or repair. Ensure all fittings are properly tightened before restoring pressure. If injury should occur, immediately seek medical attention. Failure to comply with the above warning could result in death or serious injury.

Lubricate Vacmaster® 15T Tier III Diesel Abrasive Vacuums at points indicated. Points are indicated by Lubrication Point Grease Monthly Decal (1).



1



SPECIFICATIONS

| | |
|--------------------------------|---|
| Performance: | MAX 2367 CFM |
| Filter Cartridge Style: | Acrylic-Coated Filter Bags 37 Required |
| Filter Cleaning: | Pulse System, 25–30 second intervals. Pulse Duration: 200–350 millisecond |
| Vacuum | 27" Hg |
| Ducting Connections: | 6" I.D. Inlet with 4" adapter |
| Inspection Ports: | One 10" Viewable to Filters with access ports to hopper |
| Material Removal: | Automatic Direct Dump |
| Blower: | Rotary lobe, positive displacement with jet inlet |
| Engine: | Diesel, Tier 3, 174 Horsepower |
| Fuel Capacity: | Capacity: 116 Gallons Type: Diesel |
| Air Compressor: | On Board 13 CFM |
| Electrical System: | 12-Volt DC |
| Engine Protection: | Engine Monitoring System with automatic shutdown |
| Fluid Specifications: | Hydraulic Oil: H46 or equivalent, 2 gallon capacity Diesel Fuel: See Engine Operator's Manual for type Grease/Lubricator: Shell Alvania Grease EP or equivalent Alcohol Evaporator: Alcohol 99 Isopropyl, 32 oz. capacity Vibrator Lubricator: 4 oz. pneumatic air tool oil Blower Oil: ROOTS™ synthetic lubricating oil |
| Unit Dimensions: | Weight: 11,250 pounds (empty) Length: 19' 7" Width: 7' 10" Height: 11' 6" Raised Height: 19' Dump Clearance: 8' |

MAINTENANCE

Adjust Tension of Blower Drive Belt

⚠ WARNING

W-562

Always depressurize the entire system, disconnect all power sources and lockout/tagout all components before any maintenance or troubleshooting is attempted. Failure to comply with the above warning could cause electrical shock and inadvertent activation of equipment resulting in death or serious injury.

⚠ WARNING

W-566

Moving parts can present an area where crushing, pinching, entanglement or amputation may occur. Do not place body parts or foreign objects in any area where there are moving parts.

⚠ WARNING

W-590


When performing service or maintenance on systems or devices requiring access from an elevated position, you must comply with all OSHA, local, City, State, Province, Country and jurisdiction regulations, ordinances and standards, as related to working in elevated work areas. Failure to comply with the above warning could result in death or serious injury.

⚠ WARNING




W-583

Do not walk on, stand on, or climb on any surface other than the designated work platform. Doing so poses a slip and fall hazard. Failure to comply with the above warning could result in death or serious injury.

- 1) Depressurize system.
- 2) Disconnect battery cables from battery.
- 3) Remove three Bolts (1).
- 4) Remove Front Belt Cover (2).



- 5) Inspect Belt (3) for damage. Replace as needed.
- 6) Check tension of Belt (3) by pushing downward on Belt and measure Distance (A) of travel. Belts should have a deflection distance of approximately $21/32$ inch; applied force of approximately 88–94 pounds.
- 7) To adjust tension of Belt, loosen Slide Bolts (4). Adjust threaded rod (5) until deflection distance is approximately $21/32$ inch; applied force of approximately 88–94 pounds. If distance cannot be attained, replace belt. Tighten Slide Bolts (4).
- 8) Install parts in reverse order using the following special instructions:
 - Use medium-strength thread-locker on all nuts and bolts.



MAINTENANCE


Adjust Pulse Separation

WARNING


W-562

Always depressurize the entire system, disconnect all power sources and lockout/tagout all components before any maintenance or troubleshooting is attempted. Failure to comply with the above warning could cause electrical shock and inadvertent activation of equipment resulting in death or serious injury.


- 1) Depressurize system.
- 2) Disconnect battery cables from battery.
- 3) Open enclosure door of Timer Controller.
- 4) Locate Adjustment Knobs (1 and 2).



- 5) Set the Pulse Separation, the elapsed time between pulses, by rotating Knob (3). The recommended elapsed time between pulses is 25 seconds. Depending on conditions, the elapsed time may need to be changed. Elapsed time between pulses should be between 20–30 seconds.



- 6) Set Pulse Duration, the elapsed time of compressed air entering the filters, by rotating Knob (4). The recommended elapsed time of compressed air entering the filters is 200 milliseconds (mSEC). Depending on conditions, the elapsed time of air entering the filters should be between 200–350 milliseconds.
- 7) Close enclosure door of Timer Controller.




MAINTENANCE

Hydraulic System Schematic

WARNING

W-587

Escaping fluid under pressure can penetrate skin and tissue causing injury. Stop pump and relieve pressure before attempting maintenance or repair. Ensure all fittings are properly tightened before restoring pressure. If injury should occur, immediately seek medical attention. Failure to comply with the above warning could result in death or serious injury.



- 1) Hydraulic Power Unit with Tank
- 2) Lock Valve
- 3) Cylinder
- 4) Flow Restrictor

MAINTENANCE

Remove & Install Pressure Tank

⚠ WARNING

W-562




Always depressurize the entire system, disconnect all power sources and lockout/tagout all components before any maintenance or troubleshooting is attempted. Failure to comply with the above warning could cause electrical shock and inadvertent activation of equipment resulting in death or serious injury.

NOTICE

N-530

Label all hoses and connections to aid installation.


- 1) Depressurize system.
- 2) Ensure Ball Valve (1) is open.
- 3) Depressurize Tank (2)
- 4) Disconnect Hoses and Fittings (4).
- 5) Remove Pressure Relief Valve (3).
- 6) Remove Manifold (5).
- 7) Remove Elbow (6) and Nipple (7).



- 8) Remove Alcohol Evaporator (8). See Remove & Install Alcohol Evaporator.
- 9) Remove Air Dryer (9). See Remove & Install Air Dryer.

Note: Approximate weight of Pressure Tank is 51 pounds. Use suitable lifting device to support or maneuver Pressure Tank.

- 10) Attach a suitable lifting device to Pressure Tank.
- 11) Remove four Bolts, Lock Washers, Nuts and eight Washers (10).
- 12) Remove Pressure Tank.
- 13) Install parts in reverse order using the following special instructions:
 - Use medium-strength thread-locker on all nuts and bolts.
 - Use PTFE Sealing Tape on union and fitting threads.



MAINTENANCE

Remove & Install Blower Drive Belt Assembly

⚠ WARNING

W-562

Always depressurize the entire system, disconnect all power sources and lockout/tagout all components before any maintenance or troubleshooting is attempted. Failure to comply with the above warning could cause electrical shock and inadvertent activation of equipment resulting in death or serious injury.

⚠ WARNING

W-566


Moving parts can present an area where crushing, pinching, entanglement or amputation may occur. Do not place body parts or foreign objects in any area where there are moving parts.

⚠ WARNING




W-590

When performing service or maintenance on systems or devices requiring access from an elevated position, you must comply with all OSHA, local, City, State, Province, Country and jurisdiction regulations, ordinances and standards, as related to working in elevated work areas. Failure to comply with the above warning could result in death or serious injury.

- 1) Depressurize system.
- 2) Disconnect battery cables from battery.
- 3) Remove three Bolts (1).
- 4) Remove Front Belt Cover (2).



- 5) Loosen Slide Bolts (4).
- 6) Remove tension of belt by adjusting Threaded Rods (5) until belt is loose enough to remove.
- 7) Remove Belt (3).



MAINTENANCE

Remove & Install Blower Drive Belt Assembly (Cont.)

⚠ WARNING

W-562

Always depressurize the entire system, disconnect all power sources and lockout/tagout all components before any maintenance or troubleshooting is attempted. Failure to comply with the above warning could cause electrical shock and inadvertent activation of equipment resulting in death or serious injury.

⚠ WARNING

W-566


Moving parts can present an area where crushing, pinching, entanglement or amputation may occur. Do not place body parts or foreign objects in any area where there are moving parts.

NOTICE


N-530

Label all hoses and connections to aid installation.

- 8) Remove six Bolts and Lock Washers (6) and Bushings (7).
- 9) Remove Sheaves (8) and Keys (9) from shaft.
- 10) Remove four Bolts, Lock Washers and eight Washers (10) from Belt Guard Back (11).
- 11) Remove Belt Guard Back (11).



- 12) Remove two Bolts, Lock Washers and four Washers (12) from two piece Belt Guard Bracket (13).
- 13) Remove two piece Belt Guard Bracket (13).
- 14) Install parts in reverse order using the following special instructions:
 - Use medium-strength thread-locker on all nuts and bolts.
 - Adjust blower drive belt tension. See Adjust Tension of Blower Drive Belt.



MAINTENANCE

Remove & Install Engine Assembly

⚠ WARNING


W-562

Always depressurize the entire system, disconnect all power sources and lockout/tagout all components before any maintenance or troubleshooting is attempted. Failure to comply with the above warning could cause electrical shock and inadvertent activation of equipment resulting in death or serious injury.

- 1) Depressurize system.
- 2) Remove Blower Drive Belt Cover Assembly. See Remove & Install Blower Drive Belt Cover Assembly.
- 3) Disconnect fuel supply hose and fuel return hose.
- 4) Disconnect fuel hoses and battery cables from engine. See engine Operator's Manual.
- 5) Route all hoses and wiring away from Engine Assembly.

Note: Approximate weight of Engine Assembly is 2450 pounds. Use suitable lifting devices to support or maneuver Engine Assembly.

- 6) Attach suitable lifting devices to Engine Assembly.
- 7) Remove four Washers, four Lock Washers and four Nuts (1).
- 8) Remove Engine Assembly.
- 9) Install parts in reverse order using the following special instructions:
 - Use medium-strength thread-locker on all nuts.
 - Tighten Nuts to 320 ft.-lbs.



MAINTENANCE

Remove & Install 12-Volt DC Hydraulic Power Unit With Tank

⚠ WARNING

W-562

Always depressurize the entire system, disconnect all power sources and lockout/tagout all components before any maintenance or troubleshooting is attempted. Failure to comply with the above warning could cause electrical shock and inadvertent activation of equipment resulting in death or serious injury.

⚠ WARNING

W-569

Exposure to diesel fuel, lubricant grease and oil, hydraulic oil, or engine coolant can cause personal injury. Do not allow these products to remain in contact with the skin or eyes. Ingestion of these products or inhalation of fumes from these products can cause dizziness, nausea, vomiting, or poisoning. If exposure to any of these products occurs, or if any of these products are ingested or if fumes are inhaled, please consult the product's SDS for proper first aid or medical procedures. Failure to comply with the above warning could result in death or serious injury.

NOTICE

N-530





Label all hoses and connections to aid installation.

- 1) Depressurize system.
- 2) Disconnect battery cables from battery.
- 3) Disconnect power unit electrical wires from Terminal (1).

Note: Drain hoses into container suitable for collecting fluids. Comply with all OSHA, local, City, State, Province, Country and jurisdiction regulations, ordinances and standards, related to your particular work area and environment.

Note: Hydraulic Oil Tank capacity is approximately 2 gal.

- 4) Remove Drain Plug (6) to drain hydraulic oil.
- 5) Remove Hoses (4) and Fittings (5).
- 6) Remove four Bolts, Washers, Lock Washers and Nuts (3). Remove Shield (2).
- 7) Remove two Bolts and Lock Washers (7) and remove power unit with tank.
- 8) Install parts in reverse order using the following special instructions:
 - Use medium-strength thread-locker on all nuts and bolts.



MAINTENANCE

Remove & Install Compressor

⚠ WARNING

W-562

Always depressurize the entire system, disconnect all power sources and lockout/tagout all components before any maintenance or troubleshooting is attempted. Failure to comply with the above warning could cause electrical shock and inadvertent activation of equipment resulting in death or serious injury.

⚠ WARNING

W-569

Exposure to diesel fuel, lubricant grease and oil, hydraulic oil, or engine coolant can cause personal injury. Do not allow these products to remain in contact with the skin or eyes. Ingestion of these products or inhalation of fumes from these products can cause dizziness, nausea, vomiting, or poisoning. If exposure to any of these products occurs, or if any of these products are ingested or if fumes are inhaled, please consult the product's SDS for proper first aid or medical procedures. Failure to comply with the above warning could result in death or serious injury.

NOTICE

N-530



Label all hoses and connections to aid installation.

- 1) Depressurize system.
- 2) Disconnect battery cables from battery.
- 3) Remove Housing Panel (1).


Note: Drain hoses into container suitable for collecting fluids. Comply with all OSHA, local, City, State, Province, Country and jurisdiction regulations, ordinances and standards, related to your particular work area and environment.

Note: Label all hoses and connections to aid installation.

- 4) Drain Radiator.
- 5) Disconnect Coolant Hoses (2 and 3).
- 6) Disconnect Air Hoses (4 and 5).



- 7) Note orientation and location of five Fittings (6) and remove.



MAINTENANCE


Remove & Install Compressor (Cont.)

WARNING


W-562

Always depressurize the entire system, disconnect all power sources and lockout/tagout all components before any maintenance or troubleshooting is attempted. Failure to comply with the above warning could cause electrical shock and inadvertent activation of equipment resulting in death or serious injury.


- 8) Remove Filter Assembly (7), Elbows (8), Nipple (9) and Fitting (10).



- 9) Remove Nuts (11), Bolts (12) and Compressor (13).



- 10) Remove Nut (16), Lock Washer (15), Gear (17) and O-ring (14). Inspect for wear or damage. Replace as needed.



MAINTENANCE



Remove & Install Compressor (cont.)

WARNING



W-562

Always depressurize the entire system, disconnect all power sources and lockout/tagout all components before any maintenance or troubleshooting is attempted. Failure to comply with the above warning could cause electrical shock and inadvertent activation of equipment resulting in death or serious injury.

- 11) Remove five Bolts (18) and Adapter Plate (19).
- 12) Remove and replace O-ring (20).



- 13) Install parts in reverse order using the following special instructions:
 - Align dot found on rear of compressor to timing mark "A" that is closest to timing mark "6".
 - Coat O-rings with engine oil before installing.
 - Use medium-strength thread-locker on all nuts and bolts.
 - Use PTFE Sealing Tape on all fitting threads.



MAINTENANCE

Remove & Install Governor

WARNING

W-562

Always depressurize the entire system, disconnect all power sources and lockout/tagout all components before any maintenance or troubleshooting is attempted. Failure to comply with the above warning could cause electrical shock and inadvertent activation of equipment resulting in death or serious injury.

NOTICE



N-530

Label all hoses and connections to aid installation.

- 1) Depressurize system.
- 2) Disconnect battery cables from battery.
- 3) Remove Housing Panel (1).

Note: Label all hoses and connections to aid installation.

- 4) Disconnect Air Hoses (7).
- 5) Remove Swivel Union (5), four Push-On Fittings (6), two Tees (4) and two Hex Nipples (8).
- 6) Remove two Bolts, Lock Washers and Nuts (3).
- 7) Install parts in reverse order using the following special instructions:
 - Use medium-strength thread-locker on all nuts and bolts.
 - Use PTFE Sealing Tape on union and fitting threads.



MAINTENANCE

Remove & Install Clutch

WARNING

W-562

Always depressurize the entire system, disconnect all power sources and lockout/tagout all components before any maintenance or troubleshooting is attempted. Failure to comply with the above warning could cause electrical shock and inadvertent activation of equipment resulting in death or serious injury.

WARNING

W-586

Moving parts can present an area where crushing, pinching, entanglement or amputation may occur. Do not place body parts or foreign objects in any area where there are moving parts.

NOTICE


N-530

Label all hoses and connections to aid installation.

- 1) Disconnect battery cables from battery.
- 2) Remove Blower Drive Belt Cover Assembly. See Remove & Install Blower Drive Belt Cover Assembly.


Note: Approximate weight of Clutch Assembly is 175 pounds. Use suitable lifting devices to support or maneuver Clutch Assembly.

- 3) Attach a suitable lifting device to Clutch Assembly (1).
- 4) Remove twelve Bolts (2), and remove Clutch Assembly (1).
- 5) Repair or replace Clutch Assembly (1) as needed. See Operator's Manual for Clutch Assembly.
- 6) Install parts in reverse order using the following special instructions:
 - Use medium-strength thread-locker on all nuts and bolts.



Remove & Install Vacuum Timer Control Box

- 1) Disconnect battery cables from battery.
- 2) Open enclosure door.
- 3) Remove four Screws (1).
- 4) Record connection location and label Wires (2).
- 5) Disconnect Wires (2).
- 6) Remove Conduit Hose (4).
- 7) Remove four Bolts, Washers and Nuts (3).
- 8) Remove Vacuum Timer Control Box (5).
- 9) Install parts in reverse order.
- 10) Adjust Vacuum duration and Dump duration. See Unit Startup & Shutdown.



MAINTENANCE

Remove & Install Pulser Manifold

WARNING

W-562

Always depressurize the entire system, disconnect all power sources and lockout/tagout all components before any maintenance or troubleshooting is attempted. Failure to comply with the above warning could cause electrical shock and inadvertent activation of equipment resulting in death or serious injury.

WARNING

W-590



When performing service or maintenance on systems or devices requiring access from an elevated position, you must comply with all OSHA, local, City, State, Province, Country and jurisdiction regulations, ordinances and standards, as related to working in elevated work areas. Failure to comply with the above warning could result in death or serious injury.

NOTICE


N-530

Label all hoses and connections to aid installation.


- 1) Open Ball Valve (1).
- 2) Disconnect Air Hoses (2).
- 3) Remove Light Bar (3).



- 4) Remove Connector (9) by loosening Screw (8).
- 5) Loosen two Clamps (6) and remove Hose (5) from Nipple (4).
- 6) Remove Nipple (4).
- 7) Remove Diaphragm Valve (7).
- 8) Repeat for remaining Diaphragm Valves.



- 9) Remove Fittings (10).
- 10) Remove four Bolts, eight Washers, four Lock Washers and four Nuts (12) and remove Pulser Manifold (11).
- 11) Install parts in reverse order using the following special instructions:
 - Use medium-strength thread-locker on all nuts and bolts.
 - Use PTFE Sealing Tape on union and fitting threads.



MAINTENANCE

Remove & Install Auxiliary Pulser Manifold

WARNING

W-562

Always depressurize the entire system, disconnect all power sources and lockout/tagout all components before any maintenance or troubleshooting is attempted. Failure to comply with the above warning could cause electrical shock and inadvertent activation of equipment resulting in death or serious injury.

WARNING

W-590

When performing service or maintenance on systems or devices requiring access from an elevated position, you must comply with all OSHA, local, City, State, Province, Country and jurisdiction regulations, ordinances and standards, as related to working in elevated work areas. Failure to comply with the above warning could result in death or serious injury.

NOTICE



N-530

Label all hoses and connections to aid installation.

- 1) Open Ball Valve (1).
- 2) Disconnect Air Hoses (3).


Note: Approximate weight of Auxiliary Pulser Manifold is 37 pounds. Use suitable lifting devices to support or maneuver Auxiliary Pulser Manifold.

- 3) Attach suitable lifting devices to Auxiliary Pulser Manifold (4).
- 4) Remove Fittings (2).
- 5) Remove four Bolts, eight Washers, four Lock Washers and four Nuts (5) and remove Auxiliary Pulser Manifold (4).
- 6) Install parts in reverse order using the following special instructions:
 - Use medium-strength thread-locker on all nuts and bolts.
 - Use PTFE Sealing Tape on union and fitting threads.



Remove & Install Vacuum Light Bar

- 1) Disconnect battery cables from battery.
- 2) Disconnect Cable (1).
- 3) Remove two Bolts, lock Washers, Nuts and four Washers (2).
- 4) Remove Light Bar (3).
- 5) Install parts in reverse order.



MAINTENANCE

Remove & Install Timer Board

WARNING

W-562


Always depressurize the entire system, disconnect all power sources and lockout/tagout all components before any maintenance or troubleshooting is attempted. Failure to comply with the above warning could cause electrical shock and inadvertent activation of equipment resulting in death or serious injury.

NOTICE


N-530

Label all hoses and connections to aid installation.

- 1) Disconnect battery cables from battery.
- 2) Open enclosure door.
- 3) Remove four Screws (2).
- 4) Record connection location and label Wires (1).
- 5) Disconnect Wires (1).



- 6) Install parts in reverse order using labels as a guide.
- 7) Adjust pulse duration and pulse separation. See Adjust Pulse Separation.



MAINTENANCE

Remove & Install Air Dryer

WARNING

W-562


Always depressurize the entire system, disconnect all power sources and lockout/tagout all components before any maintenance or troubleshooting is attempted. Failure to comply with the above warning could cause electrical shock and inadvertent activation of equipment resulting in death or serious injury.

NOTICE

N-530


Label all hoses and connections to aid installation.

- 1) Depressurize system.
- 2) Disconnect Air Dryer electrical connections from Electrical Box (5).
- 3) Disconnect Hoses (3) from Air Dryer (2).
- 4) Remove three Fittings (4).
- 5) Remove four Bolts, Lock Washers, Nuts and eight Washers (1). Remove Air Dryer (2).
- 6) Install parts in reverse order using the following special instructions:
 - Use medium-strength thread-locker on all nuts and bolts.
 - Use PTFE Sealing Tape on union and fitting threads.



Remove & Install Alcohol Evaporator

- 1) Depressurize system.
- 2) Drain Evaporator (2).
- 3) Disconnect Hoses (3) from Alcohol Evaporator (2).
- 4) Remove two Fittings (4) and Bushings (5).
- 5) Remove two Bolts, Lock Washers, Nuts and four Washers (1). Remove Alcohol Evaporator (2).
- 6) Install parts in reverse order using the following special instructions:
 - Fill evaporator with 32 oz. Alcohol 99 Isopropyl.
 - Use medium-strength thread-locker on all nuts and bolts.
 - Use PTFE Sealing Tape on union and fitting threads.



MAINTENANCE

Remove & Install Vacuum Control Box

WARNING

W-562


Always depressurize the entire system, disconnect all power sources and lockout/tagout all components before any maintenance or troubleshooting is attempted. Failure to comply with the above warning could cause electrical shock and inadvertent activation of equipment resulting in death or serious injury.

NOTICE

N-530

Label all hoses and connections to aid installation.

- 1) Disconnect battery cables from battery.
- 2) Open enclosure door.
- 3) Record connection location and label all Wires (2).
- 4) Disconnect Wires (2).
- 5) Remove Conduit Hoses (1).
- 6) Remove four Bolts, Washers and Nuts (3).
- 7) Remove Vacuum Control Box (4).
- 8) Install parts in reverse order using the following special instructions:
 - Use medium-strength thread-locker on all nuts and bolts.



MAINTENANCE

Remove & Install Blower

⚠ WARNING

W-562


Always depressurize the entire system, disconnect all power sources and lockout/tagout all components before any maintenance or troubleshooting is attempted. Failure to comply with the above warning could cause electrical shock and inadvertent activation of equipment resulting in death or serious injury.

NOTICE


N-530

Label all hoses and connections to aid installation.

- 1) Depressurize system.
- 2) Disconnect battery cables from battery.
- 3) Remove Blower Drive Belt Cover Assembly. See Remove & Install Blower Drive Belt Cover Assembly.
- 4) Remove Vacuum Control Box (1). See Remove and Install Vacuum Control Box.
- 5) Remove Vacuum Timer Control Box (2). See Remove and Install Vacuum Timer Control Box.
- 6) Disconnect Emergency E-Stop at Plug (3).




- 7) Remove Blower Filter Magnehelic Gauge (4). See Remove and Install Blower Filter Magnehelic Gauge.
- 8) Disconnect hoses from filter housing.
- 9) Disconnect Electrical Connector (6).
- 10) Remove Differential Pressure Switch (5).



- 11) Remove Double Bolt Clamp (8).
- 12) Remove Vacuum Hoses (7).

Note: Approximate weight of Blower Exhaust Silencer is 460 pounds. Use suitable lifting devices to support or maneuver Blower Exhaust Silencer.

- 13) Attach a suitable lifting device to Blower Exhaust Silencer (11).
- 14) Loosen top Banding Clamp (10).
- 15) Remove four Bolts, Lock Washers, Nuts and eight Washers (9).
- 16) Remove Blower Exhaust Silencer (11).



MAINTENANCE

Remove & Install Blower (Cont.)


WARNING

W-562

Always depressurize the entire system, disconnect all power sources and lockout/tagout all components before any maintenance or troubleshooting is attempted. Failure to comply with the above warning could cause electrical shock and inadvertent activation of equipment resulting in death or serious injury.


Note: Approximate weight of Intake Filter Housing is 390 pounds. Use suitable lifting devices to support or maneuver Filter Housing.

- 17) Open Valve (A) to remove any fluid build up.
- 18) Attach a suitable lifting device to Filter Housing (12).
- 19) Remove twelve Bolts, Lock Washers and Washers (13), and remove Filter Housing (12).




Note: Approximate weight of Blower Intake Silencer is 460 pounds. Use suitable lifting devices to support or maneuver Blower Intake Silencer.

- 20) Attach a suitable lifting device to Blower Intake Silencer (14).
- 21) Loosen top Banding Clamp (16).
- 22) Remove four Bolts, Lock Washers, Nuts and eight Washers (15).
- 23) Remove Blower Intake Silencer (14).



Note: Approximate weight of Silencer Mount is 140 pounds. Use suitable lifting devices to support or maneuver Filter Housing.

- 24) Attach a suitable lifting device to Silencer Mount (17).
- 25) Remove four Bolts, Lock Washers, Nuts and eight Washers (18), and remove Silencer Mount (17).
- 26) Loosen bottom Banding Clamps (19).
- 27) Remove Hoses (20) and Banding Clamps (19).



MAINTENANCE

Remove & Install Blower (Cont.)

WARNING


W-562

Always depressurize the entire system, disconnect all power sources and lockout/tagout all components before any maintenance or troubleshooting is attempted. Failure to comply with the above warning could cause electrical shock and inadvertent activation of equipment resulting in death or serious injury.

- 28) Remove twelve Bolts, Lock Washers and Washers (21), and remove Flange (22).


Note: Approximate weight of Elbow Flange is 115 pounds. Use suitable lifting devices to support or maneuver Elbow Flange.

- 29) Attach a suitable lifting device to Elbow Flange (24).
30) Remove twelve Bolts, Lock Washers and Washers (23), and remove Elbow Flange (24).



Note: Approximate weight of Blower is 1750 pounds. Use suitable lifting devices to support or maneuver Blower.

- 31) Attach a suitable lifting device to Blower (25).
32) Remove four Bolts, Nuts and eight Washers (26), and remove Blower (25).
33) Repair or replace Blower (25) as needed. See Operator's Manual for Blower.
34) Install parts in reverse order using the following special instructions:
 - Apply silicone sealant to base of flanges.
 - Use medium-strength thread-locker on all nuts and bolts.



MAINTENANCE

Remove & Install Butterfly Springs

⚠ WARNING

W-562



Always depressurize the entire system, disconnect all power sources and lockout/tagout all components before any maintenance or troubleshooting is attempted. Failure to comply with the above warning could cause electrical shock and inadvertent activation of equipment resulting in death or serious injury.

⚠ WARNING

W-590


When performing service or maintenance on systems or devices requiring access from an elevated position, you must comply with all OSHA, local, City, State, Province, Country and jurisdiction regulations, ordinances and standards, as related to working in elevated work areas. Failure to comply with the above warning could result in death or serious injury.

- 1) Open Ball Valve (1).
- 2) Remove four Bolts and Washers (3).
- 3) Remove Butterfly Cover (2).



Note: Replace springs one at a time.

- 4) Remove Outer Nut (5) and Outer Washer (6) on each end of Spring (4).
- 5) Remove Spring (4) and replace.
- 6) Install Outer Nut (5) and Outer Washer (6) on each end of Spring (4).
- 7) Repeat for remaining spring.
- 8) Install butterfly cover.



MAINTENANCE

Remove & Install Filter Bags

⚠ WARNING

W-502


Always depressurize the entire system, disconnect all power sources and lockout/tagout all components before any maintenance or troubleshooting is attempted. Failure to comply with the above warning could cause electrical shock and inadvertent activation of equipment resulting in death or serious injury.

⚠ WARNING


W-501

Breathing dust containing silica could cause silicosis, a fatal lung disease. Breathing dust during abrasive blasting operations, post-blast cleaning operations, and/or servicing equipment within the abrasive blasting area may expose an individual to conditions that could cause asbestosis, lead poisoning and/or other serious or fatal diseases. Harmful dust containing toxic material from abrasives or surfaces being abrasive blasted can remain suspended in the air for long periods of time after abrasive blasting has ceased. A NIOSH-approved, well-maintained, respirator designed for the specific operation being performed must be used by anyone abrasive blasting, handling or using the abrasive, and anyone in the area of the dust. Failure to comply with the above warning could result in death or serious injury.



- 1) Depressurize system.
- 2) Loosen Clamp (1) and remove Hose Tube (5) and Vacuum Hose (4).
- 3) Lower Lid Clamps (2) to free Lid (3).



- 4) Turn Crank (6) to raise Lid (9).
- 5) Rotate lid on Shaft (7) counterclockwise until clear of Hopper (8).



- 6) Remove four Bolts, Washers and Nuts (10). Remove Frame (11).
- 7) Remove Air Hose with Clamps (12) from Pulser System Blowpipes (13).
- 8) Remove Pulser System Blowpipes (13).
- 9) Remove Filter Bags (14).
- 10) Install parts in reverse order using the following special instructions:
 - Use medium-strength thread-locker on all nuts and bolts.



MAINTENANCE

Remove & Install Filter Cartridge

WARNING

W-562


Always depressurize the entire system, disconnect all power sources and lockout/tagout all components before any maintenance or troubleshooting is attempted. Failure to comply with the above warning could cause electrical shock and inadvertent activation of equipment resulting in death or serious injury.

WARNING


W-501

Breathing dust containing silica could cause silicosis, a fatal lung disease. Breathing dust during abrasive blasting operations, post-blast cleaning operations, and/or servicing equipment within the abrasive blasting area may expose an individual to conditions that could cause asbestosis, lead poisoning and/or other serious or fatal diseases. Harmful dust containing toxic material from abrasives or surfaces being abrasive blasted can remain suspended in the air for long periods of time after abrasive blasting has ceased. A NIOSH-approved, well-maintained, respirator designed for the specific operation being performed must be used by anyone abrasive blasting, handling or using the abrasive, and anyone in the area of the dust. Failure to comply with the above warning could result in death or serious injury.

- 1) Depressurize system.
- 2) Remove six Bolts, Lock Washers and Nuts (1).
- 3) Remove Filter Cap and Housing Gasket (2).



- 4) Remove Nut, Washer and Rubber Washer (3).
- 5) Remove Filter (4).
- 6) Install parts in reverse order using the following special instructions:
 - Use medium-strength thread-locker on all nuts and bolts.



MAINTENANCE

Remove & Install Fuel Tank

⚠ WARNING

W-562

Always depressurize the entire system, disconnect all power sources and lockout/tagout all components before any maintenance or troubleshooting is attempted. Failure to comply with the above warning could cause electrical shock and inadvertent activation of equipment resulting in death or serious injury.

⚠ WARNING

W-589

Exposure to diesel fuel, lubricant grease and oil, hydraulic oil, or engine coolant can cause personal injury. Do not allow these products to remain in contact with the skin or eyes. Ingestion of these products or inhalation of fumes from these products can cause dizziness, nausea, vomiting, or poisoning. If exposure to any of these products occurs, or if any of these products are ingested or if fumes are inhaled, please consult the product's SDS for proper first aid or medical procedures. Failure to comply with the above warning could result in death or serious injury.

NOTICE

N-531

Drain tanks into container suitable for collecting fluids. Comply with all OSHA, local, City, State, Province, Country and jurisdiction regulations, ordinances and standards, related to your particular work area and environment.

NOTICE

N-530

Label all hoses and connections to aid installation.



Note: Fuel Tank capacity is approximately 116 gallons.

Note: Drain into container suitable for collecting fluids. Comply with all OSHA, local, City, State, Province, Country and jurisdiction regulations, ordinances and standards, related to your particular work area and environment.


- 1) Remove Blower Exhaust Silencer (10), Blower Intake Silencer (11) and Silencer Mount (12). See Remove & Install Blower.
- 2) Empty fuel from Tank (9).
- 3) Disconnect Supply Hose (8) and remove Fitting (7).
- 4) Remove Withdraw Tube (6).
- 5) Disconnect electrical cable from Sensor (3) and remove sensor.
- 6) Disconnect vent hose from Hose Fitting (4) and remove fitting.
- 7) Disconnect Return Hose (1) and Fitting (2) from tank.
- 8) Remove two Bolts, Lock Washers, Nuts and four Washers (5).

Note: Approximate empty weight of Fuel Tank is 100 pounds. Use suitable lifting devices to support or maneuver Fuel Tank.

- 9) Attach a suitable lifting device to Tank (9), and remove.



- 10) Inspect Isolation Mat (13) for damage. Replace as needed.
- 11) Install parts in reverse order using the following special instructions:
 - Use medium-strength thread-locker on all nuts and bolts.
 - See engine Operator's Manual for priming of engine.



MAINTENANCE

Remove & Install Front Emergency-Stop Station

⚠ WARNING

W-562


Always depressurize the entire system, disconnect all power sources and lockout/tagout all components before any maintenance or troubleshooting is attempted. Failure to comply with the above warning could cause electrical shock and inadvertent activation of equipment resulting in death or serious injury.

NOTICE


N-530

Label all hoses and connections to aid installation.

- 1) Disconnect battery cables from battery.
- 2) Remove two Screws (1) and Cover (2).



- 3) Label Wires (4 and 5) to aid installation.
- 4) Disconnect Wires (4 and 5) and pull Cable (6) from Housing (8).
- 5) Remove two Screws, Washers, and Nuts (7) and Housing (8).
- 6) Install parts in reverse order.



MAINTENANCE

Remove & Install Pendant Emergency-Stop Station

WARNING

W-562



Always depressurize the entire system, disconnect all power sources and lockout/tagout all components before any maintenance or troubleshooting is attempted. Failure to comply with the above warning could cause electrical shock and inadvertent activation of equipment resulting in death or serious injury.

NOTICE


N-530

Label all hoses and connections to aid installation.

- 1) Disconnect Connector (1).
- 2) Remove two Screws (2) and Cover (3).
- 3) Label Wires (6 and 9) to aid installation.



- 4) Disconnect Wires (6 and 9) and pull Cable (10) from Housing (8).
- 5) Remove two Screws, Washers, and Nuts (7) and Housing (8).
- 6) Install parts in reverse order.



MAINTENANCE

Remove & Install Hopper Magnehelic Gauge

WARNING

W-562


Always depressurize the entire system, disconnect all power sources and lockout/tagout all components before any maintenance or troubleshooting is attempted. Failure to comply with the above warning could cause electrical shock and inadvertent activation of equipment resulting in death or serious injury.

NOTICE


N-530

Label all hoses and connections to aid installation.

- 1) Label Hose (2) as "Negative".
- 2) Label Hose (3) as "Positive".
- 3) Disconnect Hoses (2,3) from 90° Elbows (1,4).
- 4) Disconnect Hoses (2,3) from Magnehelic Gauge (6).
- 5) Remove Washers and Bolts (5) and Magnehelic Gauge (6).



- 6) Install parts in reverse order using the following special instructions:
- 7) Ensure labeled hoses are installed correctly. "Negative" hose installed in lower port. "Positive" hose in upper port.



MAINTENANCE

Remove & Install Blower Filter Magnehelic Gauge

WARNING

W-562


Always depressurize the entire system, disconnect all power sources and lockout/tagout all components before any maintenance or troubleshooting is attempted. Failure to comply with the above warning could cause electrical shock and inadvertent activation of equipment resulting in death or serious injury.

NOTICE


N-530

Label all hoses and connections to aid installation.

- 1) Label Hose (5) as "Negative".
- 2) Label Hose (4) as "Positive".
- 3) Disconnect Hoses (4,5) from 90° Elbows (3,6).
- 4) Disconnect Hoses (4,5) from tee fittings on Magnehelic Gauge (7).
- 5) Disconnect Hoses (1,2) from tee fittings on Magnehelic Gauge (7).



- 6) Remove three Screws (8) and Magnehelic Gauge (7).
- 7) Install parts in reverse order using the following special instructions:
 - Ensure labeled hoses are installed correctly.



MAINTENANCE

Remove & Install Pneumatic Piston Vibrators

⚠ WARNING

W-562



Always depressurize the entire system, disconnect all power sources and lockout/tagout all components before any maintenance or troubleshooting is attempted. Failure to comply with the above warning could cause electrical shock and inadvertent activation of equipment resulting in death or serious injury.

NOTICE

N-530


Label all hoses and connections to aid installation.

- 1) Depressurize system.
- 2) Close Ball Valve (1)
- 3) Disconnect Hose (2).
- 4) Remove two Bolts, Nuts and Flat Washers (4).
- 5) Remove Piston Vibrator (3).
- 6) Install parts in reverse order.



Disassemble & Assemble Diaphragm Valve

- 1) Remove Solenoid Assembly (7,8,9,10,11)
- 2) Remove four Bolts (6) and Washers (5).
- 3) Remove Cover (4).
- 4) Remove Diaphragm (3) from Base (1).
- 5) Install parts in reverse order using the following special instructions:
 - Check Vent Hole (2) is not blocked or occluded.



MAINTENANCE

Check Lubricator Oil Level

⚠ WARNING

W-562

Always depressurize the entire system, disconnect all power sources and lockout/tagout all components before any maintenance or troubleshooting is attempted. Failure to comply with the above warning could cause electrical shock and inadvertent activation of equipment resulting in death or serious injury.

⚠ WARNING

W-587


Escaping fluid under pressure can penetrate skin and tissue causing injury. Stop pump and relieve pressure before attempting maintenance or repair. Ensure all fittings are properly tightened before restoring pressure. If injury should occur, immediately seek medical attention. Failure to comply with the above warning could result in death or serious injury.

⚠ WARNING

W-589

Exposure to diesel fuel, lubricant grease and oil, hydraulic oil, or engine coolant can cause personal injury. Do not allow these products to remain in contact with the skin or eyes. Ingestion of these products or inhalation of fumes from these products can cause dizziness, nausea, vomiting, or poisoning. If exposure to any of these products occurs, or if any of these products are ingested or if fumes are inhaled, please consult the product's SDS for proper first aid or medical procedures. Failure to comply with the above warning could result in death or serious injury.

- 1) Check oil level in Sight Glass (3).
- 2) To add oil, close Ball Valve (1).
- 3) Pull down Lock Tab (2) and twist container (4) counterclockwise to release.
- 4) Add oil and install parts in reverse order.
- 5) Set oil drip rate if needed by turning the Site Dome Adjustment Screw (5).



MAINTENANCE

Remove & Install Lubricator

⚠ WARNING

W-562

Always depressurize the entire system, disconnect all power sources and lockout/tagout all components before any maintenance or troubleshooting is attempted. Failure to comply with the above warning could cause electrical shock and inadvertent activation of equipment resulting in death or serious injury.

⚠ WARNING

W-567



Escaping fluid under pressure can penetrate skin and tissue causing injury. Stop pump and relieve pressure before attempting maintenance or repair. Ensure all fittings are properly tightened before restoring pressure. If injury should occur, immediately seek medical attention. Failure to comply with the above warning could result in death or serious injury.

⚠ WARNING

W-589

Exposure to diesel fuel, lubricant grease and oil, hydraulic oil, or engine coolant can cause personal injury. Do not allow these products to remain in contact with the skin or eyes. Ingestion of these products or inhalation of fumes from these products can cause dizziness, nausea, vomiting, or poisoning. If exposure to any of these products occurs, or if any of these products are ingested or if fumes are inhaled, please consult the product's SDS for proper first aid or medical procedures. Failure to comply with the above warning could result in death or serious injury.

- 1) Depressurize system.
- 2) Ensure Ball Valve (1) is open.
- 3) Disconnect Hoses (4).
- 4) Remove Swivel (3).
- 5) Remove Ball Valve (5).
- 6) Remove Nipple (6).
- 7) Remove Swivel Union (7).
- 8) Remove Street Elbow (8).
- 9) Remove Bushings (9).
- 10) Remove two Bolts and Nuts (2).
- 11) Remove Lubricator (10).
- 12) Install parts in reverse order using the following special instructions:
 - Use medium-strength thread-locker on all nuts and bolts.
 - Use PTFE Sealing Tape on union and fitting threads.



MAINTENANCE

Remove & Install Hopper Wear Plates

⚠ WARNING

W-562

Always depressurize the entire system, disconnect all power sources and lockout/tagout all components before any maintenance or troubleshooting is attempted. Failure to comply with the above warning could cause electrical shock and inadvertent activation of equipment resulting in death or serious injury.

⚠ WARNING

W-590





When performing service or maintenance on systems or devices requiring access from an elevated position, you must comply with all OSHA, local, City, State, Province, Country and jurisdiction regulations, ordinances and standards, as related to working in elevated work areas. Failure to comply with the above warning could result in death or serious injury.

NOTICE

N-530

Label all hoses and connections to aid installation.

- 1) Depressurize system.
- 2) Close Ball Valve (1)
- 3) Disconnect Hose (2) from Piston Vibrator (4).
- 4) Remove Hose Clamp (3).
- 5) Disconnect Hoses (5) at Air Cylinder (6).
- 6) Remove Bolts, Washers, Lock Washers and Nuts (7) and move air assemblies out of way.



MAINTENANCE

Remove & Install Hopper Wear Plates (Cont.)


WARNING

W-562




Always depressurize the entire system, disconnect all power sources and lockout/tagout all components before any maintenance or troubleshooting is attempted. Failure to comply with the above warning could cause electrical shock and inadvertent activation of equipment resulting in death or serious injury.

Note: Approximate empty weight of Hopper Cone is 190 pounds. Use suitable lifting device to support or maneuver Hopper Cone .

- 7) Attach a suitable lifting device to Hopper Cone (10).
- 8) Remove 14 Bolts, Lock Washers and Nuts (9) and remove Hopper Cone (10).
- 9) Remove Gasket (8). Inspect for damage. Replace as needed.



- 10) Remove 15 Bolts, Lock Washers, Nuts and 30 Washers (11).
- 11) Remove Baffles (12). Inspect for damage. Replace as needed.
- 12) Remove four Nuts, Lock Washers and Washers (13).
- 13) Remove Wear Plate (14).
- 14) Repeat steps 11-12 for all hopper wear plates being removed.
- 15) Install parts in reverse order using the following special instructions:
 - Use medium-strength thread-locker on all nuts and bolts.



MAINTENANCE



Remove & Install Hopper Access Door Wear Plate

⚠ WARNING

W-562

Always depressurize the entire system, disconnect all power sources and lockout/tagout all components before any maintenance or troubleshooting is attempted. Failure to comply with the above warning could cause electrical shock and inadvertent activation of equipment resulting in death or serious injury.

- 1) Depressurize system.
- 2) Close Ball Valve (1)
- 3) Remove six Nuts, Lock Washers and Washers (2).
- 4) Remove Hopper Access Door (3).
- 5) Remove six Nuts, Lock Washers and Washers (5).
- 6) Remove Hopper Access Door Wear Plate (4).
- 7) Install parts in reverse order using the following special instructions:
 - Use medium-strength thread-locker on all nuts and bolts.



MAINTENANCE

Remove & Install Double Lock Valve Assembly

WARNING

W-562


Always depressurize the entire system, disconnect all power sources and lockout/tagout all components before any maintenance or troubleshooting is attempted. Failure to comply with the above warning could cause electrical shock and inadvertent activation of equipment resulting in death or serious injury.

NOTICE

N-530



Label all hoses and connections to aid installation.

- 1) Depressurize system.
- 2) Disconnect Hoses (8).
- 3) Remove Tees (3).
- 4) Remove Elbows (2).
- 5) Remove Flow Restrictor (6).
- 6) Remove Unions (4,5).
- 7) Remove two Bolts, Nuts and Lock Washers (7).
- 8) Remove Double Lock Valve (1).
- 9) Install parts in reverse order using the following special instructions:
 - Use medium-strength thread-locker on all nuts and bolts.
 - Use PTFE Sealing Tape on union and fitting threads.




MAINTENANCE

Hazard Identification Decals




MAINTENANCE

Hazard Identification Decals (cont.)




MAINTENANCE

Hazard Identification Decals (cont.)



MAINTENANCE

Hazard Identification Decals (*cont.*)



TROUBLESHOOTING

If the Vacmaster® 15T Tier III Diesel Abrasive Vacuum does not function properly, check the following:

WARNING

W-562

Always depressurize the entire system, disconnect all power sources and lockout/tagout all components before any maintenance or troubleshooting is attempted. Failure to comply with the above warning could cause electrical shock and inadvertent activation of equipment resulting in death or serious injury.

SYMPTOM (Cause)

ACTION

Diesel Engine will not start or runs poorly

(Damaged components, insufficient connections, fuel supply)

See original equipment Operator's Manual for service.

Ensure an Emergency-Stop Station is not activated. Return Emergency-Stop Station to operating position.

Inspect Emergency-Stop Stations for damage. Repair as needed.

Drive Belt slips or vibrates

(Loose connections, worn parts)

Inspect Blower Drive Belt for damage. Replace as needed.

Inspect alignment.

Adjust Blower Drive Belt Tension. See Adjust Blower Drive Belt Tension.

Magnehelic Gauge reading greater than normal operating range

(Hopper Filter Bags)

A reading greater than 40" (w.c.) on Magnehelic Gauge indicates clogged filters. Decrease engine RPM to idle speed and disengage clutch while allowing engine to run. Pulsers will clean down the filters. Once gauge reads back into the normal operation range of 20" – 30" (w.c.), re-engage clutch and increase RPM to operating speed.

If Magnehelic Gauge is reading above 30" (w.c.), perform After Use procedure. Inspect Pulser System and Filters. Replace filter bags, if needed.

If Magnehelic Gauge is reading above 40" (w.c.), shut down unit immediately. Replace filter bags.

TROUBLESHOOTING

WARNING

W-562

Always depressurize the entire system, disconnect all power sources and lockout/tagout all components before any maintenance or troubleshooting is attempted. Failure to comply with the above warning could cause electrical shock and inadvertent activation of equipment resulting in death or serious injury.

WARNING

W-586

Moving parts can present an area where crushing, pinching, entanglement or amputation may occur. Do not place body parts or foreign objects in any area where there are moving parts.

SYMPTOM (Cause)

Filter Pulser System pressurizes but does not pulse

(No power to control box, blown fuse in control box or timer board, disconnected wires, timer board, solenoid, diaphragm valve)

ACTION

Inspect all power connections. Repair or replace faulty connections.

Turn main power switch "OFF". Replace fuse if required.

Inspect all solenoids and listen for audible sound as it engages to pulse. Replace solenoid.

Inspect diaphragm valve breather vent for obstruction.

Pulser System leaks

(Loose or missing hoses or connections, loose or missing urethane tubing, damaged diaphragm valves)

Check hose and hose connections between diaphragm valves and hopper wall.

Check all tubing for secure connections and fittings. If fittings do not fit tightly in hose, cut a small section from the end of the hose and re-insert fitting in tube.

Inspect diaphragm valve for damage or debris. Repair or replace diaphragm valve.


ASSEMBLY PART NUMBERS AND SCHEMATICS

Front Assembly

| Item # | Part # | Description |
|---------------|-----------|---|
| Fig. 1 | | |
| 1 | 10103494 | Perkins Engine 174 Hp Tier 3 |
| 2 | 10104455 | Trailer |
| 3 | 10103986 | Clutch |
| 4 | 10103972 | Engine Control Panel |
| 5 | 10104821 | Wema Analog Fuel Level Gauge |
| 6 | 10103974 | Key Switch |
| — | 10103970 | Perkins Key |
| 7 | 10103969 | Murphy PowerView |
| 8 | 10103440R | 3/4-10 UNC GR8 Draw Bolt <i>(Two Required)</i> |
| 9 | 10103418 | Washer - 3/4" - Grade 8 <i>(Four Required)</i> |
| 10 | 10103420 | 3/4-10 UNC Grade 8 Nut <i>(Four Required)</i> |
| — | 10104126 | Oil Filter |
| — | 10103958 | Primary Fuel Filter |
| — | 10104117 | Secondary Fuel Filter |
| — | 10106547 | Fuel Filter Water Bowl |
| — | 10104130 | Outer Air Filter |
| — | 10104131 | Inner Air Filter |
| — | 1091147 | Vacmaster® Abrasive Vacuum Label Sheets |
| — | 109V044 | Operator's Manual - Perkins® Engine |
| — | 109V039 | Operator's Manual - Murphy PowerView® |
| — | 105M132 | Features & Specifications Guide – Vacmaster® 15T Tier III Diesel Abrasive Vacuums |
| — | 106M132 | Part Numbers & Schematics Guide – Vacmaster® 15T Tier III Diesel Abrasive Vacuums |
| — | 1090132 | Operator's Manual – Vacmaster® 15T Tier III Diesel Abrasive Vacuums |

PART NUMBERS AND SCHEMATICS

Figure 1: Front Assembly



PART NUMBERS AND SCHEMATICS


Rear Assembly

| Item # | Part # | Description |
|---------------|----------------|--|
| Fig. 2 | | |
| 1 | 10104673 | 0-50" Differential Pressure Gauge |
| 2 | 10105189 | Wear Door Liner |
| 3 | 10104665 | APV Series Piston Vibrator |
| 4 | 10104506 | Dump Door |
| 5 | 10104411 | Vacuum Hopper Cone |
| 6 | 10106511 | Vacuum Wear Door Assembly <i>(Includes Item #'s: 18, 19, 48, 49, and 50)</i> |
| 7 | 10104638 | Bulldog Trailer Jack |
| 8 | 10104439 | Knappco Hatch |
| 9 | 10105334 | Vacuum Light Bar |
| 10 | 10104498 | Vacuum Header |
| 11 | 10104459 | Blower Exhaust Silencer |
| 12 | 10104461 | Blower Intake Silencer |
| 13 | 20PFHA60UA0406 | 1/4" (M) x 3/8" (F) 90° Swivel <i>(Two Required)</i> |
| 14 | 10104667 | Pneumatic Cylinder – 2.5" |
| 15 | 10104668 | Piston Rod Clevis |
| 16 | 10104507 | Dump Arm |
| 17 | 10104234 | 3/8-16 x 1-1/4 Hex Bolt Zinc <i>(Four Required)</i> |
| 18 | 10101942 | 3/8" Flat Washer – Galvanized <i>(20 Required)</i> |
| 19 | 10101936 | 3/8" Lock Washer – Zinc <i>(16 Required)</i> |
| 20 | 1012318 | 3/8-16 Hex Nut <i>(Four Required)</i> |
| 21 | 10104512 | Dump Door Gasket |
| — | 10104511 | Dump Door Internal Plate |
| 22 | 20100160 | 1/2-13 x 4-1/2" Zinc Hex Bolt |
| 23 | 10100674 | 1/2" Flat Washer <i>(Two Required)</i> |
| 24 | 20100124 | 1/2-13 Hex Lock Nut – Zinc |
| 25 | 20PFHA25UA0404 | 1/4" Male 90° Elbow |

| Item # | Part # | Description |
|--------|----------------|--|
| 26 | 1019044 | 1/4-20 x 1-3/4" Zinc Bolt <i>(Two Required)</i> |
| 27 | 1012323 | 1/4-20 Zinc Lock Nut with Nylon Insert <i>(Two Required)</i> |
| 28 | 10104670 | Solenoid |
| 29 | 1019024 | Breather Vent |
| 30 | 10104676 | Series MPR Mini Pressure Relief |
| 31 | 10L803035 | 1/2" Close Nipple |
| 32 | 1019025 | 1/2" Straight Conduit Body |
| 33 | 10104703 | Cord Grip 1/2" Nylon .2-.47 Diameter |
| 34 | 10104678 | Pressure Gauge 100 psi 1/8" |
| 35 | 1080050 | 1/4" Ball Valve |
| 36 | 20PFHA60SG0406 | 1/4" (F) x 3/8" (F) Swivel Union <i>(Two Required)</i> |
| 37 | 20PFHA24SA0404 | 1/4" Hex Nipple <i>(Three Required)</i> |
| 38 | 1014239 | 1/8" x 1/8" 90° Fitting |
| 39 | 1011210 | 1/4" NPT x 1 1/2" Nipple |
| 40 | 20PFHA60SA0806 | 1/2" (M) x 3/8" (F) Swivel Union |
| 41 | 1011819 | 1/2" Street Elbow |
| 42 | 20100571 | 1/2" NPT 3-Way Brass Ball Valve |
| 43 | 1011818 | 1/2" x 1/4" Galvanized Bushing |
| 44 | 10104486 | Vacuum Lid Overcenter Clamp <i>(12 Required)</i> |
| 45 | 10101938 | 3/8-16 Hex Nut – Galvanized <i>(12 Required)</i> |
| 46 | 10104705 | 3/8-16 FH SQ Neck x 1" Bolt Zinc <i>(12 Required)</i> |
| 47 | 10104679 | 3/8" (M) Swivel Recoil AH 225 psi |
| — | 109V521 | Operator's Manual – Blower |

PART NUMBERS AND SCHEMATICS

Figure 2: Rear Assembly




PART NUMBERS AND SCHEMATICS

Right Side Front Assembly

| Item # | Part # | Description |
|---------------|----------------|--|
| Fig. 3 | | |
| 1 | 10104559 | Vacuum Butterfly Cover |
| 2 | 10104493 | Vacuum Aux Header |
| 3 | 10104456 | Blower Top Shaft Left Discharge |
| 4 | 10104071 | E-Stop Control Station |
| 5 | 10104579 | Vacuum Belt Guard Cover |
| 6 | 10104673 | 0–50" Differential Pressure |
| 7 | 10104614 | 10" x 8" x 4" Nema 4 Enclosure |
| 8 | 10104615 | 8" x 4" x 5" Fiberglass Latch Enclosure |
| 9 | 10104674 | Lubricator 1/2" NPT 156 CFM (<i>See Figure 5</i>) |
| 10 | 10VH620B | 6" I.D. Vacuum Hose 20' Section |
| 11 | 20RCG5050 | 1/2" NPT x .5–.625 Diameter Cord Grip |
| 12 | 20100125 | 1/4-20 x 3/4" Zinc Hex Bolt (<i>Eight Required</i>) |
| 13 | 10104703 | 1/2" NPT x .2–.47 Diameter Nylon Cord Grip (<i>Three Required</i>) |
| 14 | 20RST9050 | 90° Liquid Tite Connection Fitting |
| 15 | 10104692 | 12-Volt Pilot Light – Red |
| 16 | 20RST50 | Straight Liquid Tite Connection Fitting (<i>Two Required</i>) |
| 17 | 10104686 | 10 Amp Circuit Breaker |
| 18 | 10103305 | Selector Switch – 2-Way (<i>Three Required</i>) |
| 19 | 10106818 | Vacuum Control Timer |
| 20 | 10104109 | 6 Amp 50-Volt Rectifier |
| 21 | 10105193 | Enclosure Panel for 10104614 |
| 22 | 20PFHA25VJ02 | 1/8" Female Tee (<i>Two Required</i>) |
| 23 | 10104672 | Differential Pressure Switch |
| 24 | 20100579 | 1/4" O.D. Tube x 1/8" NPT PTC Swivel (<i>Four Required</i>) |
| 25 | 20PFBA31095614 | 1/4" Tube x 1/4" NPT 90° Fitting (<i>Two Required</i>) |
| 26 | 10104677 | Liquid Filled Vacuum Gauge |
| 27 | 1011844 | 1/4" Pipe Tee – Galvanized |
| 28 | 10104073 | Panel Lock Nut – 1/2" |
| 29 | 10101940 | 1/4" Flat Washer – Galvanized (<i>Four Required</i>) |
| 30 | 10101939 | 1/4-20 Stainless Steel Lock Nut with Nylon Insert (<i>Four Required</i>) |
| 31 | 20PFHA60UA0606 | 3/8" (M) x 3/8" (F) 90° Swivel Union (<i>Four Required</i>) |
| 32 | 10103631 | 3/8" Barb x 3/8" NPTF Brass (<i>Seven Required</i>) |
| 33 | 1011809 | 3/8" NPT Tee (<i>Two Required</i>) |
| 34 | 1011209 | 3/8 NPT Close Nipple |
| 35 | 1011747 | 3/8-16 x 1" Bolt – Zinc (<i>Four Required</i>) |
| 36 | 10101942 | 3/8" Flat Washer – Galvanized (<i>Four Required</i>) |
| 37 | 10101936 | 3/8" Lock Washer – Zinc (<i>Four Required</i>) |
| 38 | 10101938 | 3/8"-16 Hex Nut – Galvanized (<i>Four Required</i>) |
| 39 | 20PFHA60SA0606 | Union Swivel 3/8" (M) x 3/8" (F) (<i>Two Required</i>) |
| 40 | 10104048 | 6-32 x 3/8" L Pan Head Machine Screw (<i>Three Required</i>) |

PART NUMBERS AND SCHEMATICS

Figure 3: Right Side Front Assembly



PART NUMBERS AND SCHEMATICS


Right Side Center Assembly

| Item # | Part # | Description |
|---------------|----------------|--|
| Fig. 4 | | |
| 1 | 10104703 | 1/2" Npt x .2—.47 Diameter Nylon Cord Grip <i>(Two Required)</i> |
| 2 | 20000031 | 8-32 x 1-1/2" Machine Screw <i>(Two Required)</i> |
| 3 | 10105897 | Terminal Box |
| 4 | 10101943 | 1/2-13 x 1-3/4" Hex Bolt <i>(Eight Required)</i> |
| 5 | 10100674 | 1/2" Flat Washer <i>(16 Required)</i> |
| 6 | 10100675 | 1/2" Lock Washer <i>(Eight Required)</i> |
| 7 | 10101941 | 1/2-13 Hex Nut - <i>(Eight Required)</i> |
| 8 | 10104774 | 10-3/4" I.D. Hose <i>(Two Required)</i> |
| 9 | 10103416 | Banding Clamp <i>(Four Required)</i> |
| 10 | 10104715 | 7/8-9 X 2" Grade 5 Bolt |
| 11 | 10104716 | 7/8" Flat Washer - Zinc |
| 12 | 10104717 | 7/8" Lock Washer - Zinc |
| 13 | 20100195 | 3/8-16 X 1" Bolt <i>(Two Required)</i> |
| 14 | 10103400 | 3/8-16 X 3/4" Bolt <i>(Four Required)</i> |
| 15 | 1035045 | 5/16-18 x 1" Bolt <i>(Six Required)</i> |
| 16 | 10103235 | Cover |
| 17 | 10104610 | Compressed Air Tank - 15 Gal |
| 18 | 20PFHA60UA0606 | 3/8"M x 3/8"F 90° Swivel Union <i>(Three Required)</i> |
| 19 | 10104618 | 3 Outlet Pressure Manifold |
| 20 | 20PFHA60SA0604 | 3/8"M x 1/4"F Swivel Union <i>(Two Required)</i> |
| 21 | 1028617 | 3/8-16 x 1-3/4" Shoulder Bolt <i>(Four Required)</i> |
| 22 | 10101942 | 3/8" Flat Washer <i>(48 Required)</i> |
| 23 | 10101936 | 3/8" Lock Washer - Zinc <i>(15 Required)</i> |

| Item # | Part # | Description |
|--------|----------------|--|
| 24 | 1012318 | 3/8-16 Hex nut <i>(15 Required)</i> |
| 25 | 10104681 | 1/2" NPT Pressure Relief Valve |
| 26 | 10DSHP75 | 3/4" Square Head Pipe Plug <i>(Two Required)</i> |
| 27 | 1011217 | Galvanized 1/4" x 2" Nipple |
| 28 | 1011832 | Galvanized 1/4" 90° Elbow |
| 29 | 10SME025 | 1/4" NPT x 1/4" (F) Straight Swivel |
| 30 | 20PFHA60SA0606 | 3/8"M x 3/8"F Swivel Union |
| 31 | 20100195 | 3/8-16 x 1" Bolt <i>(12 Required)</i> |
| 32 | 20PFHA24SB0806 | 1/2" x 3/8" Reducing Bushing <i>(Three Required)</i> |
| 33 | 10104611 | Haldex Air Dryer |
| 34 | 1012326 | 1/4"M x 1/4"F 90° Swivel Union |
| 35 | 20PFHA60SA0806 | 1/2"M x 3/8"F Swivel Union |
| 36 | 10104612 | Haldex Alcohol Evaporator |
| 37 | 10105838 | 1/2" x 168" Stainless Steel Braided Hose Assembly with 1/2" (M) NPT Ends |
| 38 | 10104684 | 3/8" x 2' Braided Hose |
| 39 | 10104683 | 3/8" x 4-1/2' Braided Hose |
| 40 | 20PFHA60UA0808 | 1/2"M x 1/2"F 90° Swivel Union |
| 41 | 10105779 | Hydraulic Power Unit |
| 42 | 10105782 | SAE 6 x JIC 8 Elbow <i>(Two Required)</i> |
| 43 | 10104714 | 3/4-10 X 1-5/8" Bolt <i>(Eight Required)</i> |
| 44 | 10100596 | 3/4" Lock Washer <i>(Eight Required)</i> |
| 45 | 10100704 | 3/4" Flat Washer <i>(Eight Required)</i> |
| — | 10105292 | Alcohol 99 Isopropyl - 16 Oz |

PART NUMBERS AND SCHEMATICS

Figure 4: Right Side Center Assembly




PART NUMBERS AND SCHEMATICS

Right Side Rear Assembly

| Item # | Part # | Description | Item # | Part # | Description |
|---------------|----------------|--|--------|----------------|--|
| Fig. 5 | | | 26 | 1080060 | 3/8" NPT Full Port Brass Ball Valve (<i>Two Required</i>) |
| 1 | 10104559 | Vacuum Butterfly Cover | 27 | 10103624 | 1" Rubber Cushioned Loop Clamp |
| 2 | 10101942 | 3/8" Flat Washer - Galvanized (<i>Five Required</i>) | 28 | 1028617 | 3/8-16 x 1-3/4" Shoulder Bolt |
| 3 | 10103400 | 3/8-16 x 3/4" Bolt (<i>Four Required</i>) | 29 | 10101936 | 3/8" Lock Washer - Zinc |
| 4 | 10104554 | Butterfly Cover Mount Weldment | 30 | 1012318 | 3/8 -16 Hex Nut |
| 5 | 10104537 | Betts 12" Butterfly | 31 | 10104597 | Airline Drain |
| 6 | 10107175 | 6.5" Extension Spring | 32 | 20RCG5050 | 1/2" Npt x .5—.625 Diameter Cord Grip (<i>Two Required</i>) |
| 7 | 10104668 | Piston Rod Clevis | 33 | 10104671 | Vibrator Solenoid |
| 8 | 10104538 | Vacuum Butterfly Cylinder Weldment | 34 | 20PFHA60UA0406 | 1/4" (M) x 3/8" (F) 90° Swivel (<i>Two Required</i>) |
| 9 | 10104543 | Butterfly Actuating Arm | 35 | 10104703 | 1/2" Npt x .2—.47 Diameter Nylon Cord Grip (<i>Three Required</i>) |
| 10 | 20100125 | 1/4-20 x 3/4" Zinc Hex Bolt | 36 | 10101939 | 1/4-20 Stainless Steel Lock Nut with Nylon Insert (<i>Four Required</i>) |
| 11 | 10104667 | Pneumatic Cylinder - 2.5" | 37 | 10101940 | 1/4" Flat Washer - Galvanized (<i>Four Required</i>) |
| 12 | 1011824 | 1/4" Street Elbow | 38 | 20100125 | 1/4-20 x 3/4" Zinc Hex Bolt (<i>Four Required</i>) |
| 13 | 1011217 | Galvanized 1/4" x 2" Nipple | 39 | 10101942 | 3/8" Flat Washer - Galv. (<i>Eight Required</i>) |
| 14 | 10104669 | Solenoid For Butterfly | 40 | 10101938 | 3/8 -16 Hex Nut GALV. (<i>Four Required</i>) |
| 15 | 20PFHA60UA0406 | 1/4" (M) x 3/8" (F) 90° Swivel | 41 | 1011747 | 3/8 -16 x 1" Bolt - Zinc (<i>13 Required</i>) |
| 16 | 10105287 | Humphrey Din Connector | 42 | 10104546 | Vacuum Inlet Elbow |
| 17 | 10104706 | 3/8-16 x 2-1/2" Thread Stud | 43 | 10104496 | Vacuum Inlet Insert |
| 18 | 10100674 | 1/2" Flat Washer (<i>Eight Required</i>) | 44 | 10104550 | Vac Inlet Adapter |
| 19 | 20100124 | 1/2 - 13 Hex Lock Nut (<i>Eight Required</i>) | 45 | 10107797 | 4" Quick Disconnect Coupling Assy |
| 20 | 20PFHA60UA0606 | 3/8"M x 3/8"F 90° Swivel Union | 46 | 10107176 | 6.5" Long Extension Spring - Zinc |
| 21 | 20PFHA60SA0606 | Union Swivel 3/8" (M) x 3/8" (F) (<i>Three Required</i>) | 47 | 10107204 | Remote Control Pendant |
| 22 | 1011209 | 3/8 NPT Close Nipple | | | |
| 23 | 20PFHA25UG0606 | 3/8" Street Elbow | | | |
| 24 | 20PFHA24SB0806 | 1/2" x 3/8" Reducing Bushing (<i>Two Required</i>) | | | |
| 25 | 10104674 | Lubricator 1/2" NPT 156 CFM | | | |

PART NUMBERS AND SCHEMATICS

Figure 5: Right Side Rear Assembly




PART NUMBERS AND SCHEMATICS

Left Side Front Assembly

| Item # | Part # | Description |
|---------------|----------|--|
| Fig. 6 | | |
| 1 | 10104457 | Intake Filter Housing (<i>See Figure 11</i>) |
| 2 | 10104640 | 6" Double Bolt Clamp |
| 3 | 10VH620B | 6" I.D. x 20' Vacuum Hose |
| 4 | 10104082 | Jack Stand (<i>Four Required</i>) |
| 5 | 10103342 | Battery Box |
| 6 | 10104273 | Document Holder |
| 7 | 10104608 | Support Arm |
| 8 | 10105896 | Tool Box |
| 9 | 10104704 | 116 Gallon Rectangle Fuel Tank (<i>See Figure 9</i>) |
| 10 | 10104708 | Straight Grease Zerk - 1/4"-28 |
| 11 | 10106402 | 5/8-11 Grease Zerk Thru Bolt |
| 12 | 10106403 | 3/16" x 5/8" Dowel Pin |
| 13 | 10101061 | 5/8" Lock Washer |
| 14 | 10104600 | Vacuum Pin Cap |
| 15 | 10104602 | Vacuum Shoulder Pin |
| — | 10103343 | Battery Cables, 156" Long |
| — | 10103341 | Battery (<i>not shown</i>) |

PART NUMBERS AND SCHEMATICS

Figure 6: Left Side Front Assembly




PART NUMBERS AND SCHEMATICS

Left Side Center Assembly

| Item # | Part # | Description |
|---------------|----------|--|
| Fig. 7 | | |
| 1 | 10101943 | 1/2-13 x 1-3/4" Hex Bolt <i>(12 Required)</i> |
| 2 | 10100674 | 1/2" Flat Washer <i>(24 Required)</i> |
| 3 | 10100675 | 1/2" Lock Washer <i>(12 Required)</i> |
| 4 | 10101941 | 1/2-13 Hex Nut - <i>(12 Required)</i> |
| 5 | 10101927 | 1/2-13 x 3" Galvanized Hex Bolt <i>(Four Required)</i> |
| 6 | 10104584 | Silencer Mount Weldment |
| 7 | 10104461 | Blower Intake Silencer |
| 8 | 10104459 | Blower Exhaust Silencer |
| 9 | 10104824 | 8" Raincap |

PART NUMBERS AND SCHEMATICS

Figure 7: Left Side Center Assembly




PART NUMBERS AND SCHEMATICS

Left Side Rear Assembly

| Item # | Part # | Description |
|---------------|----------|--|
| Fig. 8 | | |
| 1 | 10104234 | 3/8-16 x 1-1/4" Hex Bolt Zinc <i>(Eight Required)</i> |
| 2 | 10101942 | 3/8" Flat Washer - Galvanized <i>(40 Required)</i> |
| 3 | 10101936 | 3/8" Lock Washer - Zinc <i>(11 Required)</i> |
| 4 | 1012318 | 3/8 -16 Hex Nut <i>(11 Required)</i> |
| 5 | 10104472 | Vacuum Lid Lift |
| 6 | 10104434 | Vacuum Top Section |
| 7 | 10104638 | Bulldog Trailer Jack |
| 8 | 10104728 | Lift Arm Support Bracket <i>(Two Required)</i> |
| 9 | 10104729 | Lift Arm Support Bracket Pin <i>(Two Required)</i> |
| 10 | 10104608 | Support Arm Outer <i>(Two Required)</i> |
| — | 10104605 | Support Arm Inner <i>(Two Required) (not shown)</i> |
| 11 | 10103308 | Elbow - 90° - JIC 8 x SAE 10 10 <i>(Four Required)</i> |
| 12 | 10104645 | Hopper Lift Cylinders <i>(Two Required)</i> |
| 13 | 10104646 | Lift Cylinder Clevis <i>(Two Required)</i> |
| 14 | 10104647 | 1" x 3-1/8" Pin <i>(Two Required)</i> |
| 15 | 10105290 | 3/16" x 1-5/8" Pin |
| 16 | 10104486 | Over Center Clamp <i>(12 Required)</i> |

PART NUMBERS AND SCHEMATICS


Figure 8: Left Side Rear Assembly



PART NUMBERS AND SCHEMATICS


Figure 9: Double Lock Valve Assembly

| Item # | Part # | Description |
|---------------|-----------|--|
| Fig. 9 | | |
| 1 | 10104650 | Double Lock Valve |
| 2 | 10103309 | Elbow - 90° - JIC 8 x SAE 8 (<i>Two Required</i>) |
| 3 | 10105081 | JIC 8 Tee (<i>Two Required</i>) |
| 4 | 10104651 | Union - Straight SAE 8 x JIC 8 (<i>Two Required</i>) |
| 5 | 10103613 | Union - Straight SAE 8 x SAE 8 |
| 6 | 10105288 | Flow Restrictor SAE 8 |
| 7 | 10105286 | 5/16-18 x 2-1/2" Grade 5 Zinc Bolt (<i>Two Required</i>) |
| 8 | 10L805014 | 5/16" Lock Washer (<i>Two Required</i>) |
| 9 | 1035046 | 5/16-18 Nut (<i>Two Required</i>) |



PART NUMBERS AND SCHEMATICS

Figure 10: Fuel Tank




| Item # | Part # | Description |
|--------|--------|-------------|
|--------|--------|-------------|

Fig. 10


| | | |
|----|----------------|---|
| 1 | 10104704 | 116 Gallon Rectangle Fuel Tank |
| 2 | 10103423 | 3/8" I.D. Fuel Hose (<i>Per Foot</i>) |
| 3 | 20PFHA60UA0606 | 3/8" (M) x 3/8" (F) 90° Swivel Union |
| 4 | 10103631 | 3/8" Barb x 3/8" NPT Brass Female Fitting |
| 5 | 10103617 | Withdraw Tube - 16" |
| 6 | 20PFHA60SA0606 | 3/8" (M) x 3/8" (F) Swivel Union |
| 7 | 10103618 | Straight - 3/8" NPT x 1/2" |
| 8 | 10104064 | Oetiker Clamp For 1/2" Hose |
| 9 | 10103619 | 1/2" Flexible Fuel Line (<i>Per Foot</i>) |
| 10 | 10104065 | Oetiker Clamp - 3/8" I.D. Hose |
| 11 | 10103968 | Locking Fuel Cap with Keys |
| 12 | 10104234 | 3/8-16 x 1-1/4" Hex Bolt Zinc (<i>Two Required</i>) |
| 13 | 10101942 | 3/8" Flat Washer - Galvanized (<i>Two Required</i>) |
| — | 10104631 | Fuel Tank Rubber Cushioning Pad (<i>not shown</i>) |
| — | 10103620 | 3/8" Inline Filter (<i>not shown</i>) |

Figure 11: Fan Belt Assembly



PART NUMBERS AND SCHEMATICS

Figure 12: Intake Filter Housing




| Item # | Part # | Description |
|--------|--------|-------------|
|--------|--------|-------------|

Fig. 12

| | | |
|----|-----------|---|
| 1 | 10104234 | 3/8-16 x 1-1/4" Hex Bolt Zinc <i>(Six Required)</i> |
| 2 | 10106508 | Intake Filter Housing Cap |
| 3 | 10104727 | Air Filter Housing Gasket |
| 4 | 10101936 | 3/8" Lock Washer - Zinc <i>(Four Required)</i> |
| 5 | 10101938 | 3/8-16 Hex Nut - Galvanized <i>(Four Required)</i> |
| 6 | 10104457 | Intake Filter Housing |
| 7 | 10100704 | 3/4" Flat Washer <i>(Six Required)</i> |
| 8 | 10100596 | 3/4" Lock Washer <i>(Six Required)</i> |
| 9 | 10104714 | 3/4-10 x 1-5/8" Zinc Bolt <i>(Six Required)</i> |
| 10 | 10L363 | 1/2" Npt Full Port Ball Valve |
| 11 | 10L803035 | Galvanized 1/2" Close Nipple |
| 12 | 10100674 | 1/2" Flat Washer |
| 13 | 10102005 | Rubber Washer 1.25OD x .375ID x .13 |
| 14 | 10101941 | 1/2-13 Hex Nut - Galvanized |
| 15 | 1011820 | 1-1/4" x 1/2" Bushing - Galvanized |
| — | 10102253 | Filter Cartridge |

PART NUMBERS AND SCHEMATICS


Figure 13: Vacuum Light Bar



| Item # | Part # | Description |
|----------------|----------|--|
| Fig. 13 | | |
| 1 | 10105334 | Vacuum Light Bar <i>(Includes Item #2)</i> |
| 2 | 10104086 | 2" Round LED Red Clearance Light <i>(Three Required)</i> |
| 3 | 10104703 | Cord Grip Nylon 1/2" NPT .2-.47 Diameter |
| 4 | 10101942 | 3/8" Flat Washer - Galvanized <i>(Four Required)</i> |
| 5 | 10101936 | 3/8" Lock Washer - Zinc <i>(Two Required)</i> |
| 6 | 1011747 | 3/8-16 x 1" Bolt <i>(Two Required)</i> |
| 7 | 1012318 | 3/8 -16 Hex Nut <i>(Two Required)</i> |

PART NUMBERS AND SCHEMATICS

Figure 14: Pneumatic Piston Vibrators



| Item # | Part # | Description |
|--------|--------|-------------|
|--------|--------|-------------|

Fig. 14

| | | |
|---|----------------|--|
| 1 | 20100124 | 1/2-13 Hex Lock Nut - Zinc (<i>Two Required</i>) |
| 2 | 10100674 | 1/2" Flat Washer (<i>Two Required</i>) |
| 3 | 10102652 | 1/2-13 x 2-1/4" Grade 5 Bolt (<i>Two Required</i>) |
| 4 | 20PFHA60UA0406 | 1/4" (M) x 3/8" (F) 90° Swivel Union |
| 5 | 10104665 | APV Series Piston Vibrator |


PART NUMBERS AND SCHEMATICS

Pulser System Assembly

| Item # | Part # | Description |
|----------------|----------------|--|
| Fig. 15 | | |
| 1 | 10101942 | 3/8" Flat Washer - Galvanized <i>(Eight Required)</i> |
| 2 | 10101936 | 3/8" Lock Washer - Zinc <i>(Four Required)</i> |
| 3 | 1011747 | 3/8-16 x 1" Bolt <i>(Four Required)</i> |
| 4 | 10101938 | 3/8 -16 Hex Nut <i>(Four Required)</i> |
| 5 | 20PFHA60UA0606 | 3/8"M x 3/8"F 90° Swivel Union |
| 6 | 10104498 | Vacuum Header |
| 7 | 10103736 | T-Bolt Hose Clamp For 1" I.D. <i>(10 Required)</i> |
| 8 | 10106509 | Air Hose 1" ID 200 psi - Red |
| 9 | 10104500 | 3/4" NPT x 1-1/2" Toe Nipple <i>(Five Required)</i> |
| 10 | 10105287 | Humphrey Din Connector <i>(Included with Item #16) (Five Required)</i> |
| 11 | 10104666 | 3/4" Diaphragm Valve with Solenoid <i>(Five Required)</i> |
| — | 10107192 | Pilot Valve Repair Kit |
| — | 10107193 | Diaphragm Repair Kit |


PART NUMBERS AND SCHEMATICS

Figure 15: Pulser System Assembly



PART NUMBERS AND SCHEMATICS

Figure 16: Filter Bag Pulsers




| Item # | Part # | Description |
|--------|--------|-------------|
|--------|--------|-------------|

Fig. 16

| | | |
|---|----------|--|
| 1 | 10103736 | T-Bolt Hose Clamp For 1" I.D. <i>(10 Required)</i> |
| 2 | 10106509 | 1" 75W Marine Hose - 100 PSI <i>(Five Required)</i> |
| 3 | 10104562 | Pulser System Short Blowpipe <i>(Two Required)</i> |
| 4 | 10104565 | Pulser System Medium Blowpipe <i>(Two Required)</i> |
| 5 | 10104680 | 1" Flexible Tubing For Blowpipes <i>(Two Required)</i> |
| 6 | 10104567 | Pulser System Long Blowpipe <i>(Three Required)</i> |
| 7 | 10104633 | Vacuum Baghouse Filter <i>(37 Required)</i> |
| — | 10104634 | Vacuum Baghouse Filter Cage <i>(37 Required)</i> |

PART NUMBERS AND SCHEMATICS

Figure 17: Emergency-Stop Stations



| Item # | Part # | Description |
|--------|--------|-------------|
|--------|--------|-------------|

Fig. 17

| | | |
|---|-----------------|--|
| — | 10107200 | Remote Emergency-Stop Station (Includes Item #'s: 2, 4, 5, and 6 (100')) |
| 1 | 1015552 | Female twist lock plug two prong |
| 2 | 10104071 | E-Stop Control Station |
| 3 | 1015551 | Male Twist Lock Plug Two Prong |
| 4 | 10104703 | Cord Grip Nylon 1/2"-NPT .2-.47 Diameter |
| 5 | 10104063 | Legend Plate - Emergency Stop |
| 6 | 1015540 | 16/2 Xtreme Duty Power Cord - Red |
| — | 1015009 | 8-32 x 1" Pan Head Phillips Screw (Four Required) |
| — | 20000021 | 8-32 Zinc Nut (Four Required) |
| — | 20000018 | #8 Zinc Lock Washer (Four Required) |
| — | 20000019 | #8 Zinc Flat Washer (Four Required) |


PART NUMBERS AND SCHEMATICS

Compressor Assembly

| Item # | Part # | Description |
|----------------|-----------------|--|
| Fig. 18 | | |
| — | 10105814 | Compressor 3054 Kit |
| 1 | 10106030 | Compressor to PTO Adapter |
| 2 | 10106031 | M8 x 80 Bolt <i>(Four Required)</i> |
| 3 | 10106032 | SAE A O-Ring |
| 4 | 10101062 | 5/8-11 Hex Nut |
| 5 | 10101061 | 5/8" Lock Washer |
| 6 | 10106033 | Compressor Gear |
| 7 | 10106034 | Compressor |
| 8 | 10106035 | SAE A 2-Bolt Cover with O-Ring |
| 9 | 10106036 | M8 x 16 Bolt <i>(Two Required)</i> |
| 10 | 20PFHA60SA0204 | 1/8" (M) x 1/4" (F) Swivel Union |
| 11 | 10106037 | M8 x 25 Bolt <i>(Two Required)</i> |
| 12 | 10106042 | PTO O-Ring |
| 13 | 10101941 | 1/2-13 Hex Nut <i>(Two Required)</i> |
| 14 | 10106038 | Metric Straight to NPT |
| 15 | 10103615 | M10 x 25MM Zinc Bolt <i>(Two Required)</i> |
| 16 | 10106039 | Compressor Bracket |
| 17 | 10101002 | 1/2" x 1" 90° Elbow |
| 18 | 10106040 | Metric Straight to 1/2" Hose Barb <i>(Two Required)</i> |
| 19 | 10PAF025 | 1/4" x 1/4" Push-On Fitting |
| 20 | 20PFHA60UA0808 | 1/2" (M) x 1/2" (F) 90° Swivel Union |
| 21 | 10000057 | 1/2" x 1/2" Street Elbow <i>(Two Required)</i> |
| 22 | 10L803035 | 1/2" Close Nipple |
| 23 | 10105870 | Filter Assembly <i>(Includes 10106362)</i> |
| 24 | 10106041 | Metric Straight to NPT |
| — | 10106362 | 5 Micron Filter Element <i>(Replacement Filter for 10105870)</i> |

PART NUMBERS AND SCHEMATICS


Figure 18: Compressor Assembly



PART NUMBERS AND SCHEMATICS

Figure 19: Compressor Governor


| Item # | Part # | Description |
|----------------|----------------|---|
| Fig. 19 | | |
| 1 | 10PAF025 | 1/4" x 1/4" Push on Fitting (<i>Four Required</i>) |
| 2 | 20PFHA60SA0204 | 1/8" (M) x 1/4" (F) Swivel Union |
| 3 | 20PFHA25VJ02 | 1/8" Female Tee (<i>Two Required</i>) |
| 4 | 1035046 | 5/16-18 Nut (<i>Two Required</i>) |
| 5 | 10L805014 | 5/16" Lock Washer (<i>Two Required</i>) |
| 6 | 1012905 | 1/8" Breather Muffler |
| 7 | 10105816 | Compressor Governor |
| 8 | 1014112 | 5/16-18 X 3-1/4" Hex Bolt (<i>Two Required</i>) |
| 9 | 10105717 | 1/8" Hollow Hex Pipe Plug Male (<i>Four Required</i>) |
| 10 | 20PFHA24SA0202 | 1/8" Hex Nipple (<i>Two Required</i>) |



PART NUMBERS AND SCHEMATICS

Figure 20: Vacuum Hose Support Bracket

| Item # | Part # | Description |
|----------------|----------|---|
| Fig. 20 | | |
| 1 | 10105264 | Vacuum Hose Bracket |
| 2 | 1011747 | 3/8-16 x 1" Bolt - Zinc |
| 3 | 10101942 | 3/8" Flat Washer - Galvanized |
| 4 | 10101936 | 3/8" Lock Washer - Zinc |
| 5 | 10101938 | 3/8-16 Hex Nut - Galvanized |
| 6 | 10106374 | 1.9" Diameter Conveyor Roller - 9" Long |




PART NUMBERS AND SCHEMATICS

Trailer

| Item # | Part # | Description |
|----------------|-----------------|--|
| Fig. 21 | | |
| — | 10104455 | 7 Ton Double Axle Trailer |
| 1 | 10104082 | 10,000# Heavy Spring Loaded Jack <i>(Four Required)</i> |
| 2 | 10104087 | 2" Round LED Amber Clearance Light <i>(Two Required)</i> |
| 3 | 10104088 | 2" Round Rubber Grommet <i>(Six Required)</i> |
| 4 | 10104089 | 16 - 8 Hole Pattern Rim with Tire <i>(Five Required)</i> |
| 5 | 10106084 | 7,000# Axle With Electric Brakes, Complete With Hubs And Springs 89" HF x 71" SC |
| 6 | 10104079 | Pintle Hitch with Flat Plate |
| 7 | 10104085 | Oval Rubber Grommet <i>(Two Required)</i> |
| 8 | 10104084 | Oval LED Red Tail Light <i>(Two Required)</i> |
| 9 | 10104086 | 2" Round LED Red Clearance Light <i>(Four Required)</i> |
| 10 | 10106086 | Axle Hub Only - No Bearings or Seal <i>(Two Required)</i> |
| 11 | 10106087 | Left-Hand Electric Brake Assembly <i>(Two Required)</i> |
| 12 | 10106088 | Right-Hand Electric Brake Assembly <i>(Two Required)</i> |
| 13 | 10104096 | Tire - ST235/80R/16 - 10-ply <i>(Five Required)</i> |
| 14 | 10106085 | Axle Beam/Tube Only |
| 15 | 10105746 | 5/8 x 2-1/2" Grade 8 Bolt <i>(16 Required)</i> |
| 16 | 10105747 | 5/8 Reverse Lock Nut <i>(16 Required)</i> |
| 17 | 10103398 | 5/8" Flat Washer <i>(40 Required)</i> |
| 18 | 10103397 | 5/8 x 2" Grade 8 Bolt <i>(4 Required)</i> |
| 19 | 10103393 | 5/8 Reverse Lock Nut <i>(4 Required)</i> |
| 20 | 10107126 | 16 x 6 8-Hole White Rim |
| — | 10105826 | Redline 12V - 5AH Battery Sealed |
| — | 10104081 | Breakaway Kit |
| — | 10104142 | Wire Harness - Complete <i>(Front, Middle & Rear)</i> |
| — | 10105827 | Breakaway Switch with Pin |
| — | 10104769 | 3/8" x 41" Safety Chain with Hook |
| — | 10103879 | 2" x 6" x 6" Red/White Conspicuity Tape |
| — | 10105829 | Cable With Plug |
| — | 10105826 | Redline 12V - 5AH Battery Sealed |
| — | 109V582 | Operator's Manual - Behnke Trailer |

PART NUMBERS AND SCHEMATICS

Figure 21: Trailer




PART NUMBERS AND SCHEMATICS

Wear Plates and Baffles

| Item # | Part # | Description |
|----------------|----------|---|
| Fig. 22 | | |
| 1 | 10101942 | 3/8" Flat Washer – Galvanized <i>(35 Required)</i> |
| 2 | 10101936 | 3/8" Lock Washer – Zinc <i>(35 Required)</i> |
| 3 | 10101938 | 3/8-16 Hex Nut <i>(35 Required)</i> |
| 4 | 1011747 | 3/8-16 x 1" Bolt <i>(15 Required)</i> |
| 5 | 10104489 | Vacuum Wear Plates <i>(Four Required)</i> |
| 6 | 10104490 | Vacuum Baffle <i>(Three Required)</i> |
| 7 | 10104705 | 3/8-16 FH Square Neck x 1" Bolt Zinc <i>(16 Required)</i> |
| 8 | 10101942 | 3/8" Flat Washer – Galvanized <i>(Six Required)</i> |
| 9 | 10101936 | 3/8" Lock Washer – Zinc <i>(Six Required)</i> |
| 10 | 10101938 | 3/8-16 Hex Nut – Galvanized <i>(Six Required)</i> |
| 11 | 10106511 | Vacuum Wear Door Assembly <i>(See Figure 2)</i> |

PART NUMBERS AND SCHEMATICS


Figure 22: Wear Plates and Baffles



PART NUMBERS AND SCHEMATICS

Figure 23: Hydraulic Hoses

| Item # | Part # | Description |
|----------------|----------|---|
| Fig. 23 | | |
| 1 | 10104664 | 3/8-16 x 1-1/4" Hex Bolt Zinc (<i>Eight Required</i>) |
| 2 | 10104663 | 3/8" Flat Washer - Galvanized (<i>40 Required</i>) |



ADDITIONAL TECHNICAL DATA

The associations listed below offer information, materials and videos pertaining to abrasive blasting and safe operating practices.

- **American Society for Testing and Materials (ASTM)**
100 Barr Harbor Drive
West Conshohocken, PA 19428-2959
Phone: (610) 832-9585
FAX: (610) 832-9555
www.astm.org
- **Occupational Safety & Health Administration (OSHA)**
United States
Department of Labor
200 Constitution Avenue
Washington, DC 20210
Phone: (800) 321-OSHA
(800) 321-6742
www.osha.gov
- **The National Board of Boiler & Pressure Vessel Inspectors**
1055 Crupper Avenue
Columbus, Ohio 4322
Phone: (614) 888-8320
FAX: (614) 888-0750
www.nationalboard.org
- **National Association of Corrosion Engineers (NACE)**
1440 South Creek Drive
Houston, TX 77084-4906
Phone: (281) 228-6200
FAX: (281) 228-6300
www.nace.org
- **The Society for Protective Coatings (SSPC)**
40-24th Street, 6th Floor
Pittsburgh, PA 15222-4656
Phone: (412) 281-2331
FAX: (412) 281-9992
www.sspc.org
- **American National Standards Institute (ANSI)**
1899 L Street, NW, 11th Floor
Washington, DC 20036
Phone: (202) 293-8020
FAX: (202) 293-9287
www.ansi.org

LIMITED WARRANTY

Seller warrants to the original purchaser that the Product covered by this Limited Warranty will remain free from defects in workmanship or material under normal commercial use and service for a period of one year from the date of shipment to the original Purchaser. This Warranty shall not apply to defects arising, in whole or in part, from any accident, negligence, alteration, misuse or abuse of the Product, operation of the Product which is not in accordance with applicable instructions or manuals or under conditions more severe than, or otherwise exceeding, those set forth in the written specifications for the Product, nor shall this Warranty extend to repairs or alterations of the Product and/or any maintenance part by persons other than Seller or Seller's authorized representatives. This warranty does not apply to accessory items. Further, this Warranty does not apply to damage or wear to the surface finish or appearance of the Product or normal wear and tear to the Product. This Warranty is limited to a purchaser who purchases the Product either directly from the Seller or from one of Seller's "Authorized Distributors". An Authorized Distributor is a Seller approved distributor that purchases the Product directly from the Seller for the sole purpose of re-selling the Product at retail, without any use or modifications whatsoever, to an end-purchaser. This warranty is specifically non-assignable and non-transferable.

DISCLAIMER OF WARRANTY

The foregoing Limited Warranty is exclusive and is in lieu of all other warranties, whether oral or written and whether express, implied, or statutory. SELLER HEREBY DISCLAIMS ALL OTHER WARRANTIES, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY AND/OR FITNESS FOR A PARTICULAR PURPOSE AND ALL SUCH OTHER WARRANTIES ARE HEREBY EXCLUDED AND ARE INAPPLICABLE TO THE PRODUCT. Seller makes no warranties or representations of any kind concerning respirators, or equipment made by other manufacturers. Seller's agents and representatives are not authorized to offer any further warranties.

EXCLUSIVE REMEDY FOR WARRANTY CLAIMS

THE SOLE AND EXCLUSIVE REMEDY UNDER THE FOREGOING LIMITED WARRANTY, AND TO THE EXTENT PERMITTED BY LAW, ANY WARRANTY OR CONDITION IMPLIED BY LAW, COVERING THIS PRODUCT SHALL BE, AT THE SELLER'S OPTION, THE REPAIR OR REPLACEMENT, FREE OF CHARGE, F.O.B. POINT OF MANUFACTURE, OF ANY DEFECTIVE PART OR PARTS OF THE PRODUCT THAT WERE MANUFACTURED BY SELLER, AND WHICH ARE RETURNED TO SELLER AT SELLER'S PRINCIPAL PLACE OF BUSINESS, POSTAGE PREPAID BY THE PURCHASER. THIS SOLE AND EXCLUSIVE REMEDY IS CONDITIONED UPON PURCHASER'S PROMPT WRITTEN NOTICE TO SELLER AT SELLER'S PLACE OF BUSINESS THAT A DEFECT HAS BEEN DISCOVERED, TOGETHER WITH A REASONABLY DETAILED DESCRIPTION OF THE DEFECT IN THE PRODUCT, PROOF OF PURCHASE OF THE PRODUCT, AND THE MODEL AND IDENTIFICATION NUMBER OF THE PRODUCT WITHIN THIRTY (30) DAYS AFTER DISCOVERY OF THE DEFECT, OTHERWISE SUCH CLAIMS SHALL BE DEEMED WAIVED. NO ALLOWANCE WILL BE GRANTED FOR ANY REPAIRS OR ALTERATIONS MADE BY PURCHASER OR OTHERS WITHOUT SELLER'S PRIOR WRITTEN CONSENT. IF SUCH NOTICE IS TIMELY GIVEN, SELLER WILL HAVE THE OPTION TO EITHER MODIFY THE PRODUCT OR COMPONENT PART THEREOF TO CORRECT THE DEFECT, REPLACE THE PRODUCT OR PART WITH COMPLYING PRODUCTS OR PARTS, OR REFUND THE AMOUNT PAID FOR THE DEFECTIVE PRODUCT, ANY ONE OF WHICH WILL CONSTITUTE THE SOLE LIABILITY OF SELLER AND FULL SETTLEMENT OF ALL CLAIMS. IN NO EVENT SHALL SELLER BE LIABLE FOR ANY OBLIGATION GREATER THAN THE ORIGINAL PURCHASE PRICE OF THE PRODUCT UNDER THIS WARRANTY. PURCHASER SHALL AFFORD SELLER PROMPT AND REASONABLE OPPORTUNITY TO INSPECT THE PRODUCT FOR WHICH A CLAIM IS MADE. THE SOLE PURPOSE OF THE FOREGOING STIPULATED EXCLUSIVE REMEDY SHALL BE TO REPAIR OR REPLACE DEFECTIVE PRODUCTS OR COMPONENTS THEREOF, OR TO REFUND PURCHASER THE PURCHASE PRICE THEREOF. THIS STIPULATED EXCLUSIVE REMEDY SHALL NOT BE DEEMED TO HAVE FAILED OF ITS ESSENTIAL PURPOSE SO LONG AS SELLER IS WILLING AND ABLE TO REPAIR OR REPLACE THE DEFECTIVE PARTS OR REFUND THE PURCHASE PRICE IN ACCORDANCE WITH THE TERMS HEREOF. PRODUCTS THAT HAVE BEEN REPAIRED OR REPLACED UNDER THIS WARRANTY DO NOT RECEIVE A NEW WARRANTY AND ARE ONLY COVERED BY THE REMAINING PORTION OF THE ORIGINAL WARRANTY.

LIMITATION OF REMEDIES

The foregoing stipulated exclusive remedy is in lieu of all other remedies for breach of contract, warranty, and/or tort or otherwise. Seller shall not be liable, either directly or indirectly, for any consequential, incidental or special losses or damages of Purchaser, including but not limited to the Purchaser's expenses for downtime or for making up downtime, damages for which the Purchaser may be liable to other persons and/or entities, damages to property, and injury to or death of any persons and/or any claims for incidental or consequential damages, including but not limited to loss of profits, regardless of whether Seller has been informed of the possibility of such damages. Seller neither assumes, nor authorizes any person to assume for it, any other liability in connection with the sale or use of any Products covered by the foregoing Warranty and Disclaimers, and there are no oral agreements relating to remedies which are collateral to or which affect this limitation.

GLOBAL HEADQUARTERS

- 3425 East Locust Street
Davenport, IA 52803

ph: 800.BLAST.IT (800.252.7848)

ph: 563.324.2519

fax: 563.324.6258

REGIONAL BRANCH OFFICES

- **Iowa**
Davenport
- **Louisiana**
Gonzales
Harvey
Lafayette
- **Ohio**
Youngstown
- **Texas**
Beaumont
Corpus Christi
Deer Park



ABRASIVES

BLASTING

COATING

DUST COLLECTORS

ENGINEERED SYSTEMS

RENTAL

SAFETY

SERVICE & REPAIR

VACUUMS

40+ NATIONWIDE SHIPPING LOCATIONS



★ Marco Regional Branch Offices
and Shipping Locations

● Direct Shipping Locations

CONTACT MARCO

800.BLAST.IT

(800.252.7848)

563.324.2519

FAX: 563.324.6258

WWW.MARCO.US

SALES@MARCO.US