

NOVATEK™ POWER TOOLS





PART NUMBERS AND SCHEMATICS GUIDE

Company Profile

Since 1944, Marco has developed a strong tradition of providing innovative and reliable products and services to the surface preparation and protective coatings industries. We are the world's premier provider of Abrasives, Blasting, Coating, Dust Collectors, Engineered Systems, Rental, Safety, Service, Repair, & Modernization, and Vacuums.

Through innovative designs and a total commitment to quality, Marco manufactures products that increase production rates, create a safer workplace, and reduce maintenance costs. Marco's industry experience, manufacturing capabilities, legendary customer service, product availability, logistics services, and technology leadership is your assurance that we deliver high quality products and services, providing the best value to you, our customer.

The Marco Difference

- Industry Experience With Marco on your team, you have access to expertise which can only come from decades of industry leadership. We have organized our engineering department, production specialists, customer operations, and safety support into a "Center of Competence." As a Marco customer, you have access to hundreds of years of cumulative experience related to your operations.
- Manufacturing Excellence Marco is a U.S. based, ISO 9001:2008 certified manufacturer of equipment for the Surface Preparation and Protective Coatings industries. Marco's engineers benchmark the industry to ensure that we design and manufacture superior products that set the "Gold Standard" for performance, safety, and quality.
- Legendary Customer Service Marco's legendary customer service team is staffed by friendly, highly-trained individuals who are focused on providing the highest level of product support, order accuracy, and customer satisfaction.
- Product Availability We stock over 10,000 SKU's and have more than 45 shipping locations to serve North American and International markets for all major brands of blasting and coating equipment. As the largest provider of surface preparation and protective coatings equipment in the world, our inventory levels and product availability are unmatched.
- Logistics Services Marco's in-house logistics team is dedicated to moving your shipment anywhere in the world. We move more than 14,000 truckloads every year, allowing you to save on freight costs by leveraging our buying power. Lower your process costs with a single invoice, which includes product and freight.
- Technology Leadership Our website provides: Operator's Manuals, Part Numbers and Schematics Guides, SDS information, and Features & Specifications Guides, providing access to information 24/7. Our Extranet application allows you to receive quotes and place orders online. Our Intranet maintains a complete record of your purchase history to assist with ongoing support of your existing equipment and future purchasing decisions.

Vision Statement

Marco is the world's premier provider of Abrasives, Blasting, Coating, Dust Collectors, Engineered Systems, Rental, Safety, Service, Repair, & Modernization, and Vacuums.

Mission Statement

Marco provides strong leadership and innovation to the surface preparation and protective coatings industries. We dedicate our efforts to the continuous improvement of our products, services, processes, people, and most importantly, the quality of our customer's experience.

Quality Statement

Marco is committed to providing superior quality in the design, manufacturing, distribution, rental, service, and repair of our products. Our ISO 9001:2008 certification extends throughout all operations in all locations. Continuous improvement of our processes and supply chain Integration comprise the core of our business strategy for delivering exceptional quality and value in all Marco products and services.

Management Philosophy

We are a company dedicated to the success of every customer and associate. We discuss, debate, challenge, measure, and test our ideas. We will be boundless and limitless in our passion to improve. Through sound leadership and dedicated associates, we will ensure a long term, profitable future for Marco, our associates, customers, and suppliers.

TABLE OF CONTENTS

Company Profile	2
Table of Contents	3
Novatek™ Power Tools	4-31
Novatek™ Needle and Chisel Scalers	4-17
Needle Scaler Part Numbers	4
Chisel Scaler Part Numbers	4
Needle and Chisel Scaler Kits	5
Part Numbers & Schematics	6-17
Model 1B	6-7
Model 2B	8-9
Model 3B	10-11
Model 4B	12-13
Model 2BPG	14-15
Model 3BPG	16-17
Novatek™ Vacuum Shrouded Needle	
Scalers	
Shrouded Needle Scaler Part Numbers .	
Shrouded Needle Scaler Kits	
Part Numbers & Schematics	20-25
Model 2B	
Model 2BPG	
Model 3BPG	24-25
Replacement Needles	
Replacement Chisels	
Novatek™ Peening Preparation Tools .	
Peening Preparation Tools	
Peening Preparation Tool Kits	28
Replacement Cutters	
Part Numbers & Schematics	
Novatek™ Vacuums	. 32-38
Part Numbers	
3.3 Gallon Backpack Vacuum Head	33
3.3 Gallon Backpack Vacuum Filters & Canister	34
15 Gallon Floor & 55 Gallon Drum Vacuu Head	
15 Gallon Floor Vacuum Filters & Caniste	er36
55 Gallon Drum Vacuum – Top	37
Optional Accessories	38
Maintenance Notes	39

		NOVATEK™ NEEDLE SCALERS								
		le Diameter	e Quantity	th (Inches)						
Part	Model	Needle (<i>mm</i>)	Needle	Length						
Numbers	ž	N E	ž	Le						
10TR1111099	1B	3	12	13.5						
10TR1212099	2B	3	19	14.8						
10TR1313099	3B	3	28	18.3						
10TR1333199	3BPG	3	28	13.5						
10TR1414099	4B	4	35	19						
10TR1232199	19PG	3	19	12.4						

	NOVATEK™ CHISEL SCALERS							
		Holder	(Inches)					
Part Numbers	Model	Chisel	Length					
10TR1141299	1B	1/2" Square	12.3					
10TR1242299	2B	1/2" Square	13.5					
10TR1252399	2BPG	1/2" Square	10.2					
10TR1343299	3B	1/2" Square	16.8					
10TR1353399	3BPG	1/2" Square	13.3					
10TR1353395	3BPG	5/8" Hexagon	13.3					
10TR1444299	4B	1/2" Square	17.3					


	NOVATEK™ NEEDLE AND CHISEL SCALER KITS									
Part Numbers	Model			Needle Holders	Replacement Needles		Anvil	Tool Box	3/8" X 25 Ft. Air Hose	
10TR1101099	1B	Straight	1/2 Square	3/4-1/2 Square Shank 2-1/2 Square Shank 1-3/8 Cranked - 1/2 Square	2B 2mm 1B 3mm	Flat Tip 2mm Chisel Tip 3mm	x	x	х	x
10TR1212099	2B	Round	1/2 Square	3/4-1/2 Square Shank 2-1/2 Square Shank 1-3/8 Cranked - 1/2 Square	2B 2mm 2B 3mm	Flat Tip 2mm Chisel Tip 3mm	x	x	x	N/A
10TR1222199	2BPG	Round	1/2 Square	3/4"-1/2" Square Shank 2-1/2" Square Shank 1-3/8 Cranked - 1/2 Square 2B 2mm 2B 3mm Chisel Tip 3mm		х	x	x	N/A	
10TR1323199	3BPG	Round	1/2 Square	3/4-1/2 Square Shank 2-1/2 Square Shank 1-3/8 Cranked - 1/2 Square	3B 2mm 3B 3mm	Flat Tip 2mm Chisel Tip 3mm	x	x	x	N/A
10TR1353199	3BPG	Round	5/8 Hexagon	1 Steel – 5/8 Hex 2 Steel – 5/8 Hex 4 Steel – 5/8 Hex 3B 3mm Chisel Tip 3mm		x	x	x	N/A	
10TR1303099	3B	Round	1/2 Square	3/4-1/2 Square Shank 2-1/2 Square Shank 1-3/8 Cranked - 1/2 Square3B 2mm 3B 3mmFlat Tip 2mm Chisel Tip 3mm		x	x	x	N/A	
10TR1404099	4B	Round	1/2 Square	3/4-1/2 Square Shank 2-1/2 Square Shank 1-3/8 Cranked - 1/2 Square	4B 3mm 4B 4mm	Flat Tip 4mm Chisel Tip 3mm	х	x	x	x



Novatek[™] Needle and Chisel Scalers – Model 1B

ltem #	Part #	Description
Fig. 1		
1	10TR6153021	Valve Cap
2	10TR8090139	Valve Cap O-Ring (Quantity of 10)
3	10TR7123022	Valve Spring
4	10TR6183022	Valve Stem
5	10TR8090089	Valve Stem O-Ring (Quantity of 10)
6 6A	10TR4241521 10TR4231521	Valve Body Valve Body Assembly Includes Item #'s: 1–8
7	—	Throttle Lever
8	10TR8130108	Roll Pin (Quantity of 10)
9	10TR6121001	Piston
13	10TR4111002	Body
17	10TR8090219	O-Ring (Quantity of 10)
24	10TR6102001	Anvil
25 —	10TR6011002 10TR6011003	2mm Needle Holder 3mm Needle Holder
26	—	Needles (See Page 26)
27	10TR7121001	Compression Spring
28	10TR4161032	Intermediate Tube (Includes Item #30)
29 —	10TR4171032 10TR4181032	Straight Front Tube (<i>Includes Item #30)</i> Round Front Tube (<i>Includes Item #30</i>)
30	10TR8060825	Cap Head Screw (Quantity of 10)
31	10TR4191241	Chisel Holder Assembly (Includes Item #30)
32	—	Chisel (See Page 27)
_	106M401	Part Numbers and Schematics Guide – Novatek™ Power Tools
_	109V012	Operator's Manual – Novatek™ Needle and Chisel Scalers


Figure 1: Novatek[™] Needle and Chisel Scalers – Model 1B



Novatek[™] Needle and Chisel Scalers – Model 2B

Item #	Part #	Description
Fig. 2		
1	10TR6153021	Valve Cap
2	10TR8090139	Valve Cap O-ring (Quantity of 10)
3	10TR7123022	Valve Spring
4	10TR6183022	Valve Stem
5	10TR8090089	Valve Stem O-ring (Quantity of 10)
6 6A	10TR4241521 10TR4232521	Valve Body Valve Body Assembly Includes Item #'s: 1–8)
7	—	Throttle Lever
8	10TR8130108	Roll Pin (Quantity of 10)
9	10TR6122001	Piston
13	10TR4112002	Body
24	10TR6102001	Anvil
25 —	10TR6012002 10TR6012003	2mm Needle Holder 3mm Needle Holder
26	_	Needles (See Page 26)
27	10TR7122001	Compression Spring
28	10TR4162032	Intermediate Tube (Includes Item #30)
29 —	10TR4172032 10TR4082032	Straight Front Tube <i>(Includes Item #30)</i> Round Front Tube <i>(Includes Item #30)</i>
30	10TR8060830	Cap Head Screw (Quantity of 10)
31	10TR4192241	Chisel Holder Assembly (Includes Item #30)
32	—	Chisel (See Page 27)
_	106M401	Part Numbers and Schematics Guide – Novatek™ Power Tools
_	109V012	Operator's Manual – Novatek™ Needle and Chisel Scalers


Figure 2: Novatek[™] Needle and Chisel Scalers – Model 2B



Novatek[™] Needle and Chisel Scalers – Model 3B

Item #	Part #	Description
Fig. 3		
1	10TR6153021	Valve Cap
2	10TR8090139	Valve Cap O-ring (Quantity of 10)
3	10TR7123022	Valve Spring
4	10TR6183022	Valve Stem
5	10TR8090089	Valve Stem O-ring (Quantity of 10)
6	10TR4241521	Valve Body
6A	_	Valve Body Assembly (Includes Item #'s: 1–8)
7		Throttle Lever
8	10TR8130108	Roll Pin (Quantity of 10)
9	10TR6123001	Piston
10	10TR6133001	Cylinder
13	10TR6113002	Body
15	10TR6153001	End Cap
17	10TR8090269	O-ring (Quantity of 10)
18	10TR7173011	Rubber Handle Grip
20	10TR6243001	Handle Tube
21	10TR6233001	Center Tube
22	10TR6253001	Locknut
23	10TR8109000	Sealing Washer (Quantity of 10)
24	10TR6103001	Anvil
25	10TR6013002 10TR6013003	2mm Needle Holder 3mm Needle Holder
26	10180013003	Needles (See Page 26)
20	— 10TR7123001	Compression Spring
28	10TR4163032	Intermediate Tube (Includes Item #30)
20	10TR4173032	Straight Front Tube (Includes Item #30)
23	101114173032	Straight From Tube (meldues hern #50)
30	10TR8060830	Cap Head Screw (Quantity of 10)
31	10TR4193241	Chisel Holder Assembly (Includes Item: #30)
32	_	Chisel (See Page 27)
_	106M401	Part Numbers and Schematics Guide – Novatek™ Power Tools
—	109V012	Operator's Manual - Needle and Chisel Scalers


Figure 3: Novatek[™] Needle and Chisel Scalers – Model 3B



Novatek[™] Needle and Chisel Scalers – Model 4B

ltem #	Part #	Description
Fig. 4		
1	10TR6153021	Valve Cap
2	10TR8090139	Valve Cap O-ring (Quantity of 10)
3	10TR7123022	Valve Spring
4	10TR6183022	Valve Stem
5	10TR8090089	Valve Stem O-ring (Quantity of 10)
6	10TR4241521	Valve Body
6A	_	Valve Body Assembly (Includes Item #'s: 1–8)
7	—	Throttle Lever
8	10TR8130108	Roll Pin (Quantity of 10)
9	10TR6124001	Piston
10	10TR6134001	Cylinder
13	10TR4114002	Body
15	10TR6154001	End Cap
17	10TR8090299	O-ring (Quantity of 10)
18	10TR7173011	Rubber Handle Grip
20	10TR6243001	Handle Tube
21	10TR6233001	Center Tube
22	10TR6253001	Locknut
23	10TR8109000	Sealing Washer (Quantity of 10)
24	10TR6104001	Anvil
25	10TR6014004	4mm Needle Holder
26	_	Needles (See Page 26)
27	10TR7124001	Compression Spring
28	10TR4164032	Intermediate Tube (Includes Item: #30)
29	10TR4174032	Straight Front Tube (Includes Item: #30)
-	10TR4184032	Round Front Tube (Includes Item: #30)
30	10TR8060835	Cap Head Screw (Quantity of 10)
31	10TR4194241	Chisel Holder Assembly (Includes Item: #30)
32	—	Chisel (See Page 27)
_	106M401	Part Numbers and Schematics Guide – Novatek™ Power Tools
—	109V012	Operator's Manual - Needle and Chisel Scalers


Figure 4: Novatek[™] Needle and Chisel Scalers – Model 4B



Novatek[™] Needle and Chisel Scalers – Model 2BPG

Part #	Description
10TR6153021	Valve Cap
10TR8090139	Valve Cap O-ring (Quantity of 10)
10TR7123022	Valve Spring
10TR6183022	Valve Stem
10TR8090089	Valve Stem O-ring (Quantity of 10)
_	Valve Body Valve Body Assembly <i>(Includes Item #'s: 1–8)</i>
_	Throttle Lever
10TR8130108	Roll Pin (Quantity of 10)
10TR6122001	Piston
10TR6132101	Cylinder
10TR8090249	O-ring (Quantity of 10)
10TR8090269	O-ring (Quantity of 10)
10TR4252100	Cover Assembly
10TR7173101	Rubber Handle Grip
10TR6102001	Anvil
10TR6012002 10TR6012003	2mm Needle Holder 3mm Needle Holder
—	Needles (See Page 26)
10TR7122001	Compression Spring
10TR4162032	Intermediate Tube (Includes Item: #30)
10TR4172032	Straight Front Tube (Includes Item: #30)
10TR8060830	Cap Head Screw (Quantity of 10)
10TR4192241	Chisel Holder Assembly 1/2" Square (Includes Item: #30)
—	Chisel (See Page 27)
106M401	Part Numbers and Schematics Guide – Novatek™ Power Tools
109V012	Operator's Manual – Novatek™ Needle and Chisel Scalers
	10TR6153021 10TR7123022 10TR6183022 10TR6183022 10TR8090089 10TR8130108 10TR8130108 10TR6122001 10TR6122001 10TR4090249 10TR4090269 10TR4090269 10TR4090269 10TR4090269 10TR4090269 10TR4090269 10TR4090269 10TR4090269 10TR402030 10TR7122001 10TR6012003 10TR7122001 10TR4162032 10TR4172032


Figure 5: Novatek[™] Needle and Chisel Scalers – Model 2BPG



Novatek[™] Needle and Chisel Scalers – Model 3BPG

Item #	Part #	Description
Fig. 6		
1	10TR6153021	Valve Cap
2	10TR8090139	Valve Cap O-ring (Quantity of 10)
3	10TR7123022	Valve Spring
4	10TR6183022	Valve Stem
5	10TR8090089	Valve Stem O-ring (Quantity of 10)
6	—	Valve Body
6A	<u> </u>	Valve Body Assembly (Includes Item #'s: 1–8)
7	—	Throttle Lever
8	10TR8130108	Roll Pin (Quantity of 10)
9	10TR6123001	Piston
10	10TR6133101	Cylinder
11	10TR8090289	O-ring (Quantity of 10)
12	10TR8090299	O-ring (Quantity of 10)
14	10TR4253100	Cover Assembly
18	10TR7173101	Rubber Handle Grip
24	10TR6103001	Anvil
25	10TR6013002	2mm Needle Holder
_	10TR6013003	3mm Needle Holder
26	—	Needles (See Page 26)
27	10TR7123001	Compression Spring
28	10TR4163132	Intermediate Tube (Includes Item: #30)
29	10TR4173032	Straight Front Tube (Includes Item: #30)
_	10TR4083032	Round Front Tube (Includes Item: #30)
30	10TR8060830	Cap Head Screw (Quantity of 10)
31	10TR4193341	Chisel Holder Assembly 1/2" Square (Includes Item: #30)
_	10TR4193541	Chisel Holder Assembly 5/3" Hexagon (Includes Item: #30)
32		Chisel (See Page 27)
_	106M401	Part Numbers and Schematics Guide – Novatek™ Power Tools
—	109V012	Operator's Manual – Novatek™ Needle and Chisel Scalers

Figure 6: Novatek[™] Needle and Chisel Scalers – Model 3BPG



		NOVATEK™ VACUUM SHROUDED NEEDLE SCALERS							
Part Numbers	Model	Needle Diameter (mm)	Needle Quantity	Length	Air Consumption	Blows Per Minute			
10TR1392007	2B	3	19	18.5"	5.5 CFM	3,000			
10TR1392107	2BPG	3	19	12.4"	5.5 CFM	3,000			
10TR1393107	3BPG	3	28	13.5"	8 CFM	2,200			




		NOVATEK™ VACUUM SHROUDED NEEDLE SCALER KITS									
Part Numbers	Needle Scaler Model	Heavy-Duty Tool Box	Anvil	Compression Springs	Needle Holder (2mm)	Needle Holder (3mm)	Flat Tip Needles (2mm)	Chisel Tip Needles (3mm)	Flat Cuffs	Corner Cuffs	Edge Cuffs
10TR1392000	2B	1	1	2	1	1	250	100	3	2	N/A
10TR1392100	2BPG	1	1	2	1	1	250	100	3	2	N/A
10TR1393100	3BPG	1	1	2	1	1	250	100	3	2	2



Novatek[™] Vacuum Shrouded Needle Scaler – Model 2B

Item #	# Part #	Description
Fig. 7	,	
1	10TR6153021	Valve Cap
2	10TR8090139	Valve Cap O-ring
3	10TR7123022	Valve Spring
4	10TR6183022	Valve Stem
5	10TR8090089	Valve Seat O-ring (Quantity of 10)
6	—	Valve Body
6A	—	Valve Body Assembly (Includes Item #'s: 1–8)
7	—	Throttle Lever
8	10TR8130108	Roll Pin <i>(Quantity of 10)</i>
9	10TR6122001	Piston
13	10TR4112002	Body
17	10TR8090249	O-ring (Quantity of 10)
24	10TR6102091	Anvil
25A	10TR6012093	3mm Needle Holder
25B	10TR6012092	2mm Needle Holder
26	—	Needles (See Page 26)
27	10TR7122001	Compression Spring
28	10TR4162099	Intermediate Tube (Includes Item #30)
29	10TR4182199	Front Tube with Vacuum Takeoff (Includes Item #30)
30	10TR8060830	Cap Head Screw (Quantity of 10)
31	10TR7312101	Inside Corner-Front Cuff
32	10TR7312103	Flat Edge-Front Cuff
_	106M401	Part Numbers and Schematics Guide – Novatek™ Power Tools
—	109V013	Operator's Manual – Novatek™ Vacuum Shrouded Needle Scalers


Figure 7: Novatek[™] Vacuum Shrouded Needle Scaler – Model 2B



Novatek[™] Vacuum Shrouded Needle Scaler – Model 2BPG

ltem#	Part#	Description
Fig. 8		
1	10TR6153021	Valve Cap
2	10TR8090139	Valve Cap O-ring
3	10TR7123022	Valve Spring
4	10TR6183022	Valve Stem
5	10TR8090089	Valve Seat O-ring (Quantity of 10)
6	—	Valve Body
6A	—	Valve Body Assembly (Includes Item #'s: 1-8)
7	—	Throttle Lever
8	10TR8130108	Roll Pin <i>(Quantity of 10)</i>
9	10TR6122001	Piston
10	10TR6132138	Cylinder
11	10TR8090249	O-ring (Quantity of 10)
12	10TR8090269	O-ring (Quantity of 10)
14	10TR4252138	Cover Assembly
18	10TR7173101	Rubber Handle Grip
24	10TR6102091	Anvil
25A	10TR6012093	3mm Needle Holder
25B	10TR6012092	2mm Needle Holder
26	—	Needles (See Page 26)
27	10TR7122001	Compression Spring
28	10TR4162099	Intermediate Tube (Includes Item #30)
29	10TR4182199	Front Tube with Vacuum Takeoff (Includes Item #30)
30	10TR8060830	Cap Head Screw (Quantity of 10)
31	10TR7312101	Inside Corner – Front Cuff
32	10TR7312103	Flat Edge – Front Cuff
_	106M401	Part Numbers and Schematics Guide – Novatek™ Power Tools
_	109V013	Operator's Manual – Novatek™ Vacuum Shrouded Needle Scalers


Figure 8: Novatek[™] Vacuum Shrouded Needle Scaler – Model 2BPG



Novatek[™] Vacuum Shrouded Needle Scaler – Model 3BPG

ltem#	Part#	Description
Fig. 9		
1	10TR6153021	Valve Cap
2	10TR8090139	Valve Cap O-ring
3	10TR7123022	Valve Spring
4	10TR6183022	Valve Stem
5	10TR8090089	Valve Seat O-ring (Quantity of 10)
6	—	Valve Body
6A	—	Valve Body Assembly (Includes Items: #1-#8)
8	10TR8130108	Roll Pin <i>(Quantity of 10)</i>
9	10TR6123001	Piston
10	10TR6133138	Cylinder
11	10TR8090289	O-ring (Quantity of 10)
12	10TR8090299	O-ring (Quantity of 10)
18	10TR7173101	Rubber Handle Grip
24	10TR6103011	Anvil
25A	10TR6013013	3mm Needle Holder
25B	10TR6013012	2mm Needle Holder
26	—	Needles (See Page 26)
27	10TR7123001	Compression Spring
28	10TR4163138	Intermediate Tube (Includes Item #30)
29	10TR4183039	Front Tube with Vacuum Takeoff (Includes Item: #30)
30	10TR8060830	Cap Head Screw (Quantity of 10)
31	10TR7314101	Inside Corner – Front Cuff
32	—	Flat Edge – Front Cuff
_	106M401	Part Numbers and Schematics Guide – Novatek™ Power Tools
	109V013	Operator's Manual – Novatek™ Vacuum Shrouded Needle Scalers

Figure 9: Novatek[™] Vacuum Shrouded Needle Scaler – Model 3BPG



			NE	EDLE S	CALER	S REPL	ACEM	ENT N	EDLES	5	
Part Numbers	7 Inch Length	Carbon Steel	Beryllium Copper	Flat Tip	Chisel Tip	Rivet Head	Non-Sparking	Needle Diameter	Needle Diameter	Needle Diameter	Package Quantity
10TX00057	Х	Х		Х				2mm			One Each
10TX00058	Х	Х		Х					3mm		One Each
10TX00059	Х	Х		Х						4mm	One Each
10TX00058CP	Х	Х			Х				3mm		One Each
10TX700190	Х	Х			Х	X			3mm		One Each
10TC700191	Х	Х			Х	Х				4mm	One Each
10TX00120	Х		Х	Х					3mm		One Each
1070787	Х		Х	Х			X		3mm		One Each

	NOVATEK CARBON STEEL REPLACEMENT CHISELS				
Part Numbers	Chisel Length (Inches)	Chisel Width (Inches)	Package Quantity		
10TR7041101	7	3/4	One Each		
10TR7041103	7	2	One Each		

	NOVATEK™ PEENING PREPARATION TOOLS					
Part Numbers	Work Head Width (Inches)	Electric Voltage	Length (Inches)	Width (Inches)	Height (Inches)	Cutter Style
10TR1940205	2	N/A	14	6.25	6	Flaps
10TR194C205	2	N/A	14	6.25	6	Cutters
10TR1940405	4	N/A	14	7.8	6	Flaps
10TR194C405	4	N/A	14	7.8	6	Cutters
10TR1940215	2	120	20	6.25	6	Flaps
10TR194C215	2	120	20	6.25	6	Cutters
10TR1940415	4	120	20	7.85	6	Flaps

	NOVATEK™ PEENING PREPARATION TOOL KITS					
Part Numbers	Work Head Width (Inches)	Electric Voltage				
10TR1390205	2	N/A				
10TR1390405	4	N/A				
10TR1390215	2	120				




		NOVATEK [™] PEENING PREPARATION TOOL REPLACEMENT CUTTERS				
	Part Numbers	Style	Quantity Required for 2 Inch Tool	Quantity Required for 4 Inch Tool	Package Quantity	
	10TR312S200	Star	80	160	One Each	
*	10TR312R200	Beam	80	160	One Each	
A COLORING	10TR312MRPC	C Flap	6	12	One Each	

Novatek[™] Peening Preparation Tool


ltem #	Part #	Description	ltem #	Part #	Description
Fig.10			46	10TR312A177	Lever Return Spring
1		Motor Housing	51	10TR312A105	Jet
1A		Pneumatic Motor Complete	52	10TR312A108	Jet Locking Screw
1B		Electric Motor Complete	60A	_	2" Pneumatic Shroud Assembly
2	10TR312A930	•	60B		4" Pneumatic Shroud Assembly
3	10TR312A685	•	60C		2" Electric Shroud Assembly
4	10TR312A686		60D		4" Electric Shroud Assembly
5	10TR312A451	•	61C		Cast Shroud End Plate
6	10TR312A421	Vanes (Five Required)	62		Shroud Cover Plate Hardware
7	10TR312A415	Rear Bearing Housing	63A		2" Shroud Positioning Roller (Qty of 2)
8	10TR312A346	Front Bearing Housing	63B		4" Shroud Positioning Roller (Qty of 2)
9	10TR312A101	Rotor Spacer	64A 64B		2" Roller Axles (<i>Quantity of Two</i>) 4" Roller Axles (<i>Quantity of Two</i>)
10	10TR312A604	Bearing	65		Roller Hardware Set
11	10TR312A689	Bearing	66A	1011(300D217	2" Peening Tool Gasket
12	10TR312A722	Bearing	66B		4" Peening Tool Gasket
13	10TR312A723	Bearing	67A		Air Motor to Shroud Hardware
14	10TR312A605	Bearing	67B		Collar to Shroud Hardware
15	10TR312A725	Spindle	67C	10TR5080221	Collar to Motor Hardware
16	_	Circlip	68A	_	Pneumatic Collar
17	10TR312A142	Circlip	68B	10TR312E200	Electric Collar
18	10TR312A724	Bearing Housing	70A		2" Star Cutter Hub Assembly
19/20	10TR312A727	Gear Wheel/Pinion Set	70B		4" Star Cutter Hub Assembly
21	10TR312A612	Wrench - Open End (19mm)	72A 72B		2" Pin-Flat Retainer (Quantity of Six)
22	10TR8180255	1/4" NPT x 3/8" MQC Plug			4" Pin-Flat Retainer (<i>Quantity of Six</i>)2" RotoPeen Flabs Hub Assembly
23	10TR312A102	Governor	76A 76B		4" RotoPeen Flabs Hub Assembly
24	10TR312A249	Oiling Screw	78A		2" Star Hub Axle (<i>Quantity of Four</i>)
	10TR312A254	Oiler - Gear Lube	78B		4" Star Hub Axle (<i>Quantity of Four</i>)
26	10TR312A626	Rear Spacer	79		Plate Axle Retainer
27	10TR612A172	Wood Ruff Key	80	10TR508D212	Plate Axle Star Hub Hardware
28	10TR312A728	Front Spacer		106M401	Part Numbers and Schematics
29	10TR312A729	Coupling			Guide – Novatek™ Power Tools
30	10TR312A730	Back Flange		109V011	Operator's Manual – Novatek™
34	10TR312A732	Silencer Cover and Screws			Peening Preparation Tools
35	10TR312A342	Lever			
38	_	Throttle Housing			
40	10TR312A141	Lever Pin			
41	10TR312A330	O-ring			
42	10TR312A143	Throttle Valve Stem			
43	_	Valve Spring			
44	10TR312A113	O-ring			
45	_	Throttle Plug			
		-			

Figure 10: Novatek™ Peening Preparation Tool




	NOVATEK™ HEPA FILTERED VACUUMS				
Part Numbers	Model	Power Source	Capacity (Gallons)	Tank Material	
10TR3053100	Backpack	Pneumatic	3.3	Stainless Steel	
10TR3053150	Backpack	Electric	3.3	Stainless Steel	
10TR3073100	Floor	Pneumatic	15	Stainless Steel	
10TR3073350	Floor	Electric	15	Steel	

Figure 11: Novatek™ 3.3 Gallon Backpack Vacuum Head



Item a	# Part #	Description
Fig. 1	1	
1	10TR3100302	Dome Assembly with Handle
2	10TR3100325	T-Connector External Assembly
3	10TR3100324	Ball Valve
4	10TR3100304	Hose Assembly External
5	10TR3100323	Hose Clamp
6	10TR3100317	Screws (Quantity of 10)
7	10TR3100319	Acorn Nuts (Quantity of 10)
8	10TR3100318	Hex Nut (Quantity of 10)
9	10TR3100330	1/2" Quick Connect
10	10TR3100331	Brass Elbow
11	10TR3100332	Bulk Head
12	10TR3100333	Tubing
13	10TR3100346	Air Dryer/Filter Bowl – Complete
14	10TR3100348	1/2" Brass Nipple
15	—	T-Connector Internal Assembly
16	10TR3100305	Hose Assembly Internal
17	10TR3100335	Pressure Gauge
18	10TR3100322	Muffler
19	_	Venturi
20	10TR3100320	Outer Can Cover
21	_	Screws (Quantity of 10)
_	106M405	Part Numbers and Schematics Guide – Novatek™ Power Tools
	109V111	Operator's Manual – Novatek™ Vacuums

Figure 12: Novatek[™] 3.3 Gallon Backpack Vacuum – Filters & Canister




ltem	# Part #	Description
Fig. '	12	
1	10TR3100342	HEPA Filter Gasket
2	10TR3053133	HEPA Filter with Gasket – 12" Diameter
3	10TR3100310	Pre-Filter – 12" Diameter (Quantity of Two)
4	10TR3053120	3.3 Gallon Disposable Bags (Quantity of Five)
5	10TR3100303	Stainless Steel Can Assembly
6	10TR3100341	14" Gasket
7	10TR3100340	Speed Pin (Quantity of Two)
8	10TR3100301	Frame – Complete
		Includes Shoulder and Waist Harness
9	10TR3100343	Mounting Clip
11	10TR3100337	Head Retaining Clip
	106M405	Part Numbers and Schematics Guide – Novatek™ Power Tools
—	109V111	Operator's Manual – Novatek™ Vacuums

Figure 13: Novatek[™] 15 Gallon Floor and 55 Gallon Drum Vacuum Head


	4 D- 4 4	
	# Part #	Description
Fig. 1	10TR3100302	Domo Accombly with Handle
2	10TR3100302	Dome Assembly with Handle T-Connector External Assembly
2	10TR3100323	Ball Valve
3 4	10TR3100324	Acorn Nuts (Quantity of 10)
5	10TR3100318	Hex Nut (Quantity of 10)
6	10TR3100332	Bulk Head
7	10TR3100333	Tubing
8	10TR3100346	Air Dryer/Filter Bowl – Complete
_	10TR3100347	Cartridge for Air Dryer/Filter Bowl
9	10TR3100348	1/2" Brass Nipple
10	_	T-Connector Internal Assembly
11	10TR3100305	Hose Assembly Internal
12	10TR3100335	Pressure Gauge
13	10TR3100322	Muffler
14	_	Venturi
15	10TR3101016	16" Cover Assembly
16	10TR3101017	Mounting Plate
17	10TR3101018	Screws (Quantity of 10)
18	—	Screws (Quantity of 10)
19	10TR3101019	Gasket
20	10TR3100330	1/2" Quick Connect
21	10TR3200328	Air-Relief Valve
	10TR3083570	Wet/Dry Conversion Kit Adapter
	106M405	Part Numbers and Schematics Guide – Novatek™ Power Tools
	109V111	Operator's Manual – Novatek™ Vacuums

Figure 14: Novatek[™] 15 Gallon Floor Vacuum – Filters & Canister



Item # Part #		Description
Fig. 14		
1	10TR3101011	HEPA Filter/Gasket Assembly – 14" Diameter
2	10TR3101010	Pre-Filter – 14" Diameter (Quantity of Two)
3	10TR3101012	Paper Disposable Bags (Quantity of Five)
4	10TR3101520	15 Gallon Stainless Steel Can Assembly
	10TR3101521	15 Gallon Steel Can Assembly
7	10TR3101514	Push Handle
8	10TR3101515	Glide Mobile Dolly Base
9	10TR3101517	Rear Wheel & Hub Cap
10	10TR3101015	Ball Bearing caster
11	10TR3101519	Fastener Set
12	10TR3100338	Drain Valve Assembly
13	10TR3100337	Head Retaining Clip
	106M405	Part Numbers and Schematics Guide – Novatek™ Power Tools
	109V111	Operator's Manual – Novatek™ Vacuums

Figure 15: Novatek™ 55 Gallon Vacuum Drum – Top



Item # Part #		Description
Fig. 1	15	
1	10TR3101011	HEPA Filter/Gasket Assembly – 14" Diameter
	10TR3101099	Cloth Filter
2	10TR3101010	Pre-Filter – 14" Diameter (Quantity of Two)
3	10TR3100337	Head Retaining clip
4	10TR3083450	Wet/Dry Adapter Section – 16"
5	10TR3083470	Float, Wet/Dry Adapter
6	10TR3085502	Lift Handles (Two Required)
7	10TR3083459	Drum Adapter – 1 Port
	10TR3083469	Drum Adapter – 3 Port
8	10TR3080559	Gasket
9	10TR3085475	Inlet Fitting Assembly
10	10TR3089445	1-1/2" Hose Connector
11	10TR3080613	Elbow Diverter Assembly
_	10TR3100336	55 Gallon PolySafety Disposal Bags (Quantity of Five)
	10TR3083570	Wet/Dry Conversion Kit Adapter
—	106M405	Part Numbers and Schematics Guide – Novatek™ Power Tools

OPTIONAL ACCESSORIES

	1-1/2" I.D. VACUUM HOSE	
Part Numbers	Vacuum Hose I.D.	ength
10VH11250	1-1/2"	
10TR7193150	1-1/2"	Per Foot

Part	1-1/2" I.D. VACUUM HOSE ACCESSORIES
 Numbers	Description
10TR8283150	1-1/2" I.D. Vacuum Hose Cuff
10TR8383100	1-1/2" I.D. Vacuum Hose Union

Part	55 GALLON DRUM	
Numbers	Description	
1070056	55 Gallon Steel Drum with Lid	

MAINTENANCE NOTES

DATE	TYPE OF SERVICE	PART NUMBER

GLOBAL HEADQUARTERS

 3425 East Locust Street Davenport, IA 52803

ph: 800.BLAST.IT (800.252.7848) ph: 563.324.2519 fax: 563.324.6258

REGIONAL BRANCH OFFICES

- lowa
 Davenport
- Louisiana Gonzales Harvey Lafayette
- Ohio
 Youngstown
- Texas Beaumont Corpus Christi Deer Park



40+ NATIONWIDE SHIPPING LOCATIONS

Marco Regional Branch Offices and Shipping Locations Direct Shipping Locations



ABRASIVES BLASTING COATING DUST COLLECTORS ENGINEERED SYSTEMS RENTAL SAFETY SERVICE, REPAIR, & MODERNIZATION VACUUMS

CONTACT MARCO

800.BLAST.IT (800.252.7848) 563.324.2519 FAX: 563.324.6258

WWW.MARCO.US SALES@MARCO.US