
Powered Air HX5[®] PAPR

Simplifying your protection.

With the simple press of a button, experience clean filtered air in an instant as the HX5 removes up to 99.97% of particulates down to 0.12 microns from your breathing air - making the HX5 ideal across a wide range of medical personnel in emergency responses, to manufacturers in the pharmaceutical industry.

Through its robust housing, the HX5 is able to withstand the physical demands of multiple applications, while incorporating sleek considered surfaces for ease of cleaning and disinfecting. With the HX5's vertical mounting positioning, this enhances your experience of comfort as this evenly distributes its weight to help relieve you of the effects of fatigue.

The HX5 simplifies your protection, so you can focus on the task at hand.



Features & Benefits

Weighing just 2.55lbs (1.16kg) with the HE filter fitted, the sleek, lightweight and compact design maximizes your experience of comfort. Through vertical mounting, the HX5 contours to you and the flexi-belt system ensures its support.

Visual and audible alarms alert you when the battery level is low, or when airflow falls below the minimum requirements due to the filter needing replacing or when airflow is obstructed.

Fixed fan speed for ease of use.

The HX5 unit attaches via our intuitive mount lock system, allowing the unit to be easily removed when wiped down for cleaning and decontamination purposes.



PAPR backpack assembly option available for applications that require a greater range of movement and work across varied angles.

Ingress protection – The HX5 is certified to IP53, allowing it to withstand dust and rainfall. ■

■ Cartridge/Filter Safety - The cartridge/filter door cannot mount to the unit unless a cartridge/filter is fixed in place.

■ HE filter removes up to 99.97% of particulates down to 0.12 microns. Replace the pre-filter daily to extend the life of the main cartridge/filter.





Sealed inside the unit during operation, the long-life lithium-ion battery is protected and will not disconnect or bump off while operating.

For more information visit rpbsafety.com/healthcare/hx5

Certifications









Want to know more? Contact us

rpbsafety.com/healthcare

Request a quote rpbsafety.com/healthcare/request-a-quote

Or call us toll-free at 1-866-494-4599



youtube.com/rpbsafety



⚠ WARNING

PRODUCT SELECTION

- 1. Determine what type of protection is required for your activity. As applicable, check your workplace safety program, respiratory protection program, and standards and regulations for your activity or industry.
- **2. Check product specifications.** Contact RPB® or check the product instruction manual (downloadable from rpbsafety.com) for complete specifications, including approvals, standards, and regulations to which the product conforms.
- 3. Make sure you have a complete system. Verify that you have or are purchasing all required components. System requirements are available from RPB® or in product instruction manuals.

Selecting inappropriate or incomplete equipment, including the use of counterfeit or non-RPB® parts, can result in inadequate protection and will void the NIOSH approval of the entire respirator.

without the prior written permission of RPB IP, LLC. You may not alter or remove any trademark, copyright or other notice from copies of the content.

The green and gray color combination is a registered trademark of RPB IP, LLC. All rights in the RPB Intellectual Property contained in this publication, including copyright, trademarks, service marks, trade secret, and patent rights are reserved. RPB Intellectual Property means any patent, patented articles, patent applications, designs, industrial designs, copyrights, software, source code, database rights, moral rights, inventions, techniques, technical data, trade secrets, know-how, brands, trademarks, trade names, slogans, logos, and any other common law and proprietary rights, whether registered or unregistered anywhere in the world, that are owned by, developed in whole or in part by, or licensed by RPB IP, LLC.

DuPont™ Tychem® is a registered trademark of E.I. du Pont de Nemours and Company or its affiliates.

